



SIEMENS



Learn-/Training Document

Siemens Automation Cooperates with Education
(SCE) | As of Version V15.1

TIA Portal Module 102-101
RFID-Sensor Technology with RF210R IO-Link,
ET 200SP and SIMATIC S7-1500

[siemens.com/sce](https://www.siemens.com/sce)

SIEMENS

Global Industry
Partner of
WorldSkills
International



Matching SCE trainer packages for this Learn-/Training Document

Industrial Identification SIMATIC RFID-Sensor Technology

- **SIMATIC RF200 RFID-System IO-Link**
Order no.: 6GT2096-5AA00-0AA0
- **SIMATIC RF200 RFID-System PROFINET**
Order no.: 6GT2096-3AA00-0AA0
- **SIMATIC RF200 RFID-System IO-Link**
Order no.: 6GT2096-5AA00-0AA0
- **SIMATIC RF300 RFID-System PROFINET**
Order no.: 6GT2096-1AA00-0AA0

SIMATIC ET 200SP Distributed IO

- **SIMATIC ET 200SP Digital**
Order no.: 6ES7155-6AU00-0AB0
- **SIMATIC ET 200SP Digital with Input Module ENERGY METER PN**
Order no.: 6ES7155-6AU00-0AB1
- **SIMATIC ET 200SP Digital with Communication Module IO-LINK MASTER V1.1 PN**
Order no.: 6ES7155-6AU00-0AB2
- **SIMATIC ET 200SP Digital with Communication Module CM AS-i MASTER ST PN**
Order no.: 6ES7155-6AU00-0AB3
- **SIMATIC ET 200SP Analog Module Extension**
Order no.: 6ES7155-6AU00-0AB6

SIMATIC Controllers

- **SIMATIC ET 200SP Distributed Controller CPU 1512SP F-1 PN Safety**
Order no.: 6ES7512-1SK00-4AB2
- **SIMATIC CPU 1516F PN/DP Safety with Software**
Order no.: 6ES7516-3FN00-4AB2
- **SIMATIC S7 CPU 1516-3 PN/DP with Software**
Order no.: 6ES7516-3AN00-4AB3
- **SIMATIC CPU 1512C PN with Software and PM 1507**
Order no.: 6ES7512-1CK00-4AB1
- **SIMATIC CPU 1512C PN with Software, PM 1507 and CP 1542-5 (CP PROFIBUS)**
Order no.: 6ES7512-1CK00-4AB2
- **SIMATIC CPU 1512C PN with Software**
Order no.: 6ES7512-1CK00-4AB6
- **SIMATIC CPU 1512C PN-1 without Power Supply / with CP for PROFIBUS DP**
Order no.: 6ES7512-1CK00-4AB7

SIMATIC STEP 7 Software for Training

- **SIMATIC STEP 7 Professional V15.1 - Single license**
Order no.: 6ES7822-1AA05-4YA5
- **SIMATIC STEP 7 Professional V15.1 - Classroom License for 6 Users**
Order no.: 6ES7822-1BA05-4YA5
- **SIMATIC STEP 7 Professional V15.1 - Upgrade License for 6 Users**
Order no.: 6ES7822-1AA05-4YE5
- **SIMATIC STEP 7 Professional V15.1 - Student License for 20 Users**
Order no.: 6ES7822-1AC05-4YA5

SIMATIC Panels and WinCC Advanced Software

- **SIMATIC TP700 Comfort Color Panel**
Order no.: 6AV2133-4AF00-0AA0

- **TP1500 Comfort Color Panel**
Order no.: 6AV2133-4BF00-0AA0
- **SIMATIC WinCC Advanced V15 - Classroom License for 6 Users**
Order no.: 6AV2102-0AA05-0AS5
- **SIMATIC WinCC Advanced V15 - Upgrade License for 6 Users**
Order no.: 6AV2102-4AA05-0AS5
- **SIMATIC WinCC Advanced V15 - Student License for 20 Users**
Order no.: 6AV2102-0AA05-0AS7

Please note that these trainer packages are replaced with successor packages when necessary.
An overview of the currently available SCE packages is provided under: siemens.com/sce/tp

Training courses

For regional Siemens SCE training courses, contact your regional SCE representative:
siemens.com/sce/contact

Additional information regarding SCE

siemens.com/sce

Information regarding use

The SCE Learn-/Training Document for the integrated automation solution Totally Integrated Automation (TIA) was prepared for the program "Siemens Automation Cooperates with Education (SCE)" specifically for training purposes for public educational and R&D institutions. Siemens does not guarantee the contents.

This document is only to be used for initial training on Siemens products/systems. This means it can be copied in whole or in part and given to trainees/students for use within the scope of their training/course of study. Disseminating or duplicating this document and sharing its content is permitted within public training and advanced training facilities for training purposes or as part of a course of study.

Exceptions require written consent from the Siemens. Send all related requests to scesupportfinder.ia@siemens.com.

Offenders will be held liable. All rights including translation are reserved, particularly if a patent is granted or a utility model or design is registered.

Use for industrial customer courses is expressly prohibited. We do not consent to commercial use of the training documents.

We wish to thank the TU Dresden, especially Prof. Dr.-Ing. Leon Urbas and the Michael Dziallas Engineering company and all other involved persons for the support in the preparation of this SCE Learn-/Training Document.

TABLE OF CONTENTS

1	Goal	5
2	Requirement	5
3	Required hardware and software	6
4	Theory.....	8
4.1	IO-Link Master CM 4xIO-Link	8
4.1.1	Technical properties	8
4.1.2	Description of the IO-Link Master CM 4xIO-Link	9
4.1.3	Status and error displays	9
4.1.4	Device exchange IO-Link Master CM 4xIO-Link with electronic coding element.....	4
4.2	S7-PCT Port Configuration Tool Software.....	5
4.2.1	Properties of the S7-PCT Port Configuration Tool	5
4.3	SIMATIC RF210R IO-Link Reader	6
4.3.1	Technical specifications of the RF200 IO-Link-Reader	7
4.3.2	Transmission window and read/write distance	8
4.3.3	Working in static and dynamic mode	9
4.3.4	Installation guidelines	9
4.3.5	Connecting cable	10
4.3.6	Pin assignment RF200 reader with IO-Link interface	10
4.3.7	Pin assignments of the IO-Link Master from Siemens	10
4.4	IOL_READ_WRITE_DATA_LIB_V3.1 library (LRfidIOL_V15).....	11
4.4.1	Blocks of the library	11
4.4.2	FB "LRfidIOL_Read"	12
4.4.3	FB "LRfidIOL_Write"	13
4.4.4	FB "LRfidIOL_Antenna"	14
5	Task	15
6	Planning	16
7	Structured step-by-step instructions	17
7.1	Retrieving an existing project.....	17
7.2	ET 200SP: Inserting and configuring the IO-Link Master	19

7.3	Loading the hardware configuration and assigning device names.....	21
7.4	Inserting and configuring RF210R IO-Link RFID-Sensor with device tool (S7-PCT)	25
7.5	Creating data types for raw data and user data	30
7.6	Data blocks for the RFID-Read and write data.....	31
7.7	Blocks from the IOL_READ_WRITE_DATA_LIB_V3.1 library	33
7.8	"Read_Write_RFID_Data" function block	34
7.9	Testing the application with the watch table_RFID	42
7.10	Accessing data with a Panel TP700 Comfort	43
7.11	Archive the project	51
7.12	Checklist – step-by-step instructions	52
8	Exercise	53
8.1	Task – Exercise	53
8.2	Planning.....	54
8.3	Checklist – Exercise	54
9	Additional information	55

RFID-Sensor Technology with RF210R IO-LINK on ET 200SP and SIMATIC S7-1500

1 Goal

The following pages show how an RF210R IO-Link RFID-Sensor can be put into operation on an IO-Link module in a project with SIMATIC S7-1500 and ET 200SP and how data can be written and read to mobile data media using the blocks from the "IOL_READ_WRITE_DATA_LIB_V3.1" library. Read and write operations are performed via a visualization on a SIMATIC TP700 Comfort panel, which must also be created.

2 Requirement

This chapter builds on the chapter Distributed Hardware Configuration with SIMATIC S7-1500 and ET 200SP on PROFINET. To perform the work in this chapter, you can use the following project, for example:

"SCE_EN_012-201 Distributed Hardware Configuration S7-1500 ET 200SP PN.....zap15".

You also need previous knowledge about the basics of programming in the TIA Portal, handling data blocks and creating a process visualization for a SIMATIC Panel TP700 Comfort with WinCC Advanced.

3 Required hardware and software

- 1 Engineering station: requirements include hardware and operating system
(for additional information, see Readme on the TIA Portal Installation DVD)
- 2 SIMATIC STEP 7 Professional software in TIA Portal – as of V15.1
- 3 WinCC Advanced software in TIA Portal – as of V15.1
- 4 Software S7-PCT Port Configuration Tool – as of V3.5
- 5 SIMATIC S7-1500 controller, e.g. CPU 1516F-3 PN/DP –
as of firmware V2.5 with memory card
- 6 ET 200SP Distributed IO for PROFINET with 16DI/16DO as well as 2AI/1AO and IO-Link
Master

Example configuration:

Interface module IM155-6PN HF with BusAdapter BA 2xRJ45

2x IO module 8x digital input DI 8x24VDC HF

2x IO module 8x digital output DQ 8x24VDC/0.5A HF


2x IO module 2x analog input AI 2xU/I 2, 4-wire HS

IO module 2x analog output AQ 2xU/I HS

Communication module IO-Link Master CM 4xIO-Link as of firmware V2.1

Server module

- 7 Readers of the RF200 Family with IO-Link interface, e.g. SIMATIC RF210R IO-Link with
reader cable and RFID-Transponder
- 8 SIMATIC Panel TP700 Comfort
- 9 Ethernet connection between engineering station and controller,
between controller and ET 200SP distributed IO and
between ET 200SP distributed IO and Panel TP700 Comfort



4 Theory

The data of an RFID-Transponder in this document is to be read and write accessed.

For this, we use the RF210R IO-Link RFID-Sensor on an IO-Link Master CM 4xIO-Link. This must be commissioned with the S7-PCT Port Configuration Tool software.

The program uses blocks from the "IOL_READ_WRITE_DATA_LIB_V3.1" library.

The basic information from the SIEMENS manuals is provided here.

4.1 IO-Link Master CM 4xIO-Link


IO-Link is a point-to-point connection between a master and a device. Both conventional and intelligent sensors/actuators in proven 3-wire technology can be connected to the IO-Link Master via unshielded standard cables. Switching status and data channel are designed in proven 24 V DC technology.

4.1.1 Technical properties

The IO-Link Master module, CM 4xIO-Link, has the following technical features:


- *Serial communication module with 4 ports (channels)*
- *SIO mode (standard IO mode)*
- *IO-Link Master according to IO-Link Specification V1.1*
- *Time-based IO (time stamping) as of FW V2.0*
- *Data transmission rates COM1 (4.8 kbaud), COM2 (38.4 kbaud), COM3 (230.4 kbaud)*
- *Suitable for connecting up to 4 IO-Link devices (3-wire connection) or 4 standard encoder or standard actuators*
- *Cable length unshielded, maximum 20 m*
- *Programmable diagnostics function by port*
- *Automatic backup of the master and device parameters via electronic coding element*
- *The IO-Link port configuration is performed with the S7-PCT Port Configuration Tool*
- *Variable address range of the IO data with up to 32 bytes inputs and 32 bytes outputs as of FW V2.0 / 144 bytes inputs and 128 bytes outputs as of FW V2.1*
- *IO-Link port configuration without S7-PCT as of FW V2.2*

4.1.2 Description of the IO-Link Master CM 4xIO-Link



- | | |
|---------------------------------------|---|
| 1) Module type and name | 8) Color coding module type |
| 2) LED for diagnostics | 9) Function and firmware version |
| 3) QR code | 10) BU type |
| 4) Connection diagram | 11) Color code for selecting the color-coded labels |
| 5) LEDs for status and error displays | 12) Article number |
| 6) LED for supply voltage | |
| 7) Function class | |

4.1.3 Status and error displays



- | | |
|-------------------------------------|-------------|
| 1) Diagnostics (DIAG) | (green/red) |
| 2) Port status/IO-Link status (Cn) | (green) |
| 3) Channel status in SIO modus (QN) | (green) |
| 4) Port error (Fn) | (red) |
| 5) Supply voltage L + (PWR) | (green) |

4.1.4 Device exchange IO-Link Master CM 4xIO-Link with electronic coding element

When you remove the communication module from the BaseUnit, part of the electronic coding element remains plugged into the BaseUnit. The parameters of the IO-Link Master CM 4xIO-Link as well as the parameters of the IO-Link devices are stored in this part. A newly inserted (not yet configured) IO-Link Master takes over the parameters from the electronic coding element.

Note:

- *Only disconnect and plug in the IO-Link Master CM 4xIO-Link communication module when it is de-energized. If you plug the IO-Link Master CM 4xIO-Link communication module when it is energized, this can damage the ET 200SP distributed IO system and thus create dangerous conditions in your system.*

You can see more details in the manuals at support.automation.siemens.com

4.2 S7-PCT Port Configuration Tool Software

IO-Link Master modules from SIEMENS and IO-Link devices from any manufacturer can be configured with the S7-PCT Port Configuration Tool. The parameter data of the IO-Link devices can be set, modified, copied and saved in the TIA Portal project here.

The S7-PCT Port Configuration Tool is called via the hardware configuration of the IO-Link Masters.

4.2.1 Properties of the S7-PCT Port Configuration Tool

Properties of the S7-PCT Port Configuration Tool

- *Available free-of-charge as download in the Internet*
(support.industry.siemens.com/cs/document/32469496)
- *Import IODD (IO Device Description) for IO-Link devices from different manufacturers*
- *Configuration screens (tabs) in S7-PCT with plain text and product image directly from the IODD of the certified device*
- *Central data storage of all project data in the TIA Portal project*
- *Extensive test and diagnostic functions*
- *Read identification data from the devices*
- *Read back device information including parameter settings*

Ensure that the current IODD files (IO-Link V1.1) are included in the catalog. If they are not, import them via the menu "Tools" > "Import IODD".

You can find the latest IODD files on the DVD "RFID-Systems Software & Documentation" (6GT2080-2AA20) or on the pages of Siemens Industry Online Support

support.industry.siemens.com/cs/products?dtp=Download&mfn=ps&pnid=14972&lc=en-DE.

You can see more details in the manuals at support.automation.siemens.com

4.3 SIMATIC RF210R IO-Link Reader

SIMATIC RF200 IO-Link is an inductive identification system compatible with the ISO 15693 standard, which was specially designed for use in industrial production for control and optimization of material flow. Readers can be used below the fieldbus level with the IO-Link communication interface.

SIMATIC RF200 IO-Link is a simple and cost-effective solution for RFID-Applications.



- 1) RF200 IO-Link interface
- 2) LED operating display

The operating states of the reader are indicated by the LED. The LED can be green, red or yellow and the states off, on or flashing.

The IO-Link reader reads either the UID or user-specific data of a transponder and maps this into cyclically updated process data. User-specific data can also be written.

This data can be imported via the IO-Link Master from a PC or a controller.

4.3.1 Technical specifications of the RF200 IO-Link-Reader

The IO-Link reader has the following features:

- *Point-to-point communication, no address setting of the IO-Link device required*
- *Supports only IO-Link Masters according to specification V1.1*
- *IO-Link transmission speed 230.4 Kbps*
- *Maximum data transmission rate wireless transmission 26.6 Kbps*
- *Process data in the process image: 32 bytes of input and 32 bytes of output*
- *User data in the process image: 28 bytes of input and 28 bytes of output*
- *Typical transfer time for user data per byte*
 - *for write access (for 28-byte block) 3.6 ms/byte*
 - *for read access (for 28-byte block) 2.4 ms/byte*
- *Transmission of service data in parallel to process data*
- *Parameter upload/download functionality for device exchange (parameter server)*
- *SIO mode (reader indicates the presence of a transponder on the data line (C/Q))*
- *IODD file for support of parameter assignment, diagnostics and data access*
- *Degree of protection IP67*
- *RFID-Operating frequency nominal value 13.56 MHz according to ISO 15693, ISO 18000-3*


4.3.2 Transmission window and read/write distance


The reader generates an inductive alternating field. The field is at its greatest near the reader, however, the "zero" read/write distance between reader and transponder is not recommended.

The field strength of the alternating field decreases strongly with the distance to the reader. The distribution of the field depends on the structure and geometry of the antennas in the reader and transponder.

The function of the transponder requires a minimum field strength at the transponder, which is just reached at a distance S_g (limit distance) from the reader.

The following figure shows the transmission window of the SIMATIC RF210R reader between transponder and reader:



 Transmission window

Sa: Working distance between transponder and reader


Sg: Limit distance (limit distance is the maximum clear distance between reader top and transponder, where the transmission just barely works under normal conditions).

L: Diameter of a transmission window.

SP: Intersection of the transponder's symmetry axis.

4.3.3 Working in static and dynamic mode

When working in static mode, the transponder can be operated up to the range of the limit distance (S_g). The transponder must be positioned exactly above the reader:



In static mode, the dwell time t_v (application-dependent) can be as long as desired. The dwell time must be at least until communication with the transponder has been completed.

Working in dynamic mode is not recommended for RF200 IO-Link.

4.3.4 Installation guidelines


Transponders and readers with their antennas are inductive devices. Any kind of metal in the vicinity of these devices affects their operation. A few points must be observed during configuration and installation:

- *Minimum distance between two readers or their antennas*
- *Minimum distance between two adjacent transponders*
- *Installation of several readers or their antennas on metal frames or carriers for shielding*
- *Flush installation of the components in metal reduces the field data; testing is recommended for critical applications.*
- *Metal-free space for flush installation of readers or their antennas and transponders in metal*
- *Direct mounting on metal is only permitted with specially approved transponders.*
- *When working in the transmission window, it must be ensured that no metal rail (or similar) intersects the transmission field. The metal rail would affect the field data.*

4.3.5 Connecting cable

The connecting cable has a length of 5 m or 10 m.

Structure of the connecting cable between IO-Link Master with single-wire connection technology and reader:



4.3.6 Pin assignment RF200 reader with IO-Link interface

Pin	Pin Device end 4-pin M12	Assignment
	1	24 VDC
	2	reserved
	3	GND
	4	IO-Link data signal or switching output port in SIO mode

4.3.7 Pin assignments of the IO-Link Master from Siemens

Pin assignment for the CM 4xIO-Link electronic module (6ES7137-6BD00-0AB0)					
Terminal	Assignment	Terminal	Assignment	Explanations	Color labeling plate
1	C/CQ1	2	C/CQ2	<ul style="list-style-type: none"> C/Q: Communication signal RES: Reserved, must not be used L+: Supply voltage (positive) M: Ground 	
3	C/CQ3	4	C/CQ4		
5	RES	6	RES		
7	RES	8	RES		
9	L + 1	10	L + 2		
11	L + 3	12	L + 4		
13	M	14	M		
15	M	16	M		
L+	24 V DC	M	Ground		CC04 6SE7193-6CP04-2MA0

You can see more details in the manuals at support.automation.siemens.com

4.4 IOL_READ_WRITE_DATA_LIB_V3.1 library (LRfidIOL_V15)

With the blocks of this library, the RF200 IO-Link Reader (V1.0/V1.1) can be controlled via a very simple user interface.

Tested SIMATIC modules with clearly defined interfaces can be used to implement the task.

Note:

- The library is available for the SCE Learn-/Training Document "SCE_EN_102-101_RFID-Sensor_RF210R_IO-Link_ET 200SP_S7-1500..." in the projects folder, but can also be downloaded from SIEMENS Product Support with the following link:
support.industry.siemens.com/cs/document/73565887.

4.4.1 Blocks of the library




Communication between the CPU and an RF200 reader with IO-Link interface is realized via a corresponding IO-Link Master module by reading the corresponding configured address ranges (input and output ranges) of the RF200 IO-Link reader.

The following table lists all blocks belonging to the "IOL_READ_WRITE_DATA_LIB_V3.1 (LRfidIOL_V15)" library.

Block	Function	Description/Classification
LRfidIOL_Read	Read	Function block for reading from the transponder.
LRfidIOL_Write	Write	Function block for writing to the transponder.
LRfidIOL_Antenna	Switching antenna on/off	Function block for switching the antenna of an RF200 IO-Link reader on/off.




4.4.2 FB "LRfidIOL_Read"

The "LRfidIOL_Read" library block reads a data block from the transponder. The following table shows the call interface of the FB "LRfidIOL_Read" library block.

	Symbol	Data type	Explantation
INPUT	excute	BOOL	Read job activated at positive edge.
	adrTag	WORD	Start address of the data to be read on the transponder.
	length	WORD	Length of the data that is read from the transponder.
	hwId	HW_SUBMODULE	Hardware identifier of the IO-Link communication module. 
	portAdr	INT	Start address of the connected reader (PCT Tool)  Example: Start address 0.0, the value "0" has to be entered in PORT_ADR.
IN / OUT	identData	Variant	Area in the S7-CPU where the read data is stored (global data block). 
OUTPUT	done	BOOL	TRUE if the last job has been completed without errors (for one cycle). FALSE if a new command is started.
	busy	BOOL	TRUE if the "LRfidIOL_Read" block is active. FALSE if the job was stopped or if an error occurred.
	error	BOOL	FALSE, if a command was completed without errors. TRUE if an error occurs when processing (for one cycle). Default value: FALSE
	status	DWORD	<ul style="list-style-type: none"> DW#16#00, if a command was completed without errors. In the case of an error (ERROR=TRUE) Hex value unequal zero (see Chapter 2.4). Remains on this value for one cycle.
	presence	BOOL	Presence bit. This bit is only set if a transponder is in the field of the reader.



4.4.3 FB "LRfidIOL_Write"

The "LRfidIOL_Write" library block writes a data block to a transponder. The following table shows the call interface of the FB "LRfidIOL_Write" library block.

	Symbol	Data type	Explanation
INPUT	excute	BOOL	Enables the write job at positive edge.
	adrTag	WORD	Start address of the data to be written on the transponder.
	length	WORD	Length of the data that is written to the transponder. Note: The reader writes at least 4 (V1.0) or 28 bytes V1.1 to the transponder. This is why a length larger than 4 (V1.0) or 28 bytes (V1.1) has to be chosen.
	hwId	HW_SUBMODULE	Hardware identifier of the IO-Link communication module. 
	portAdr	INT	Start address of the connected reader (PCT Tool)  Example: Start address 0.0, the value "0" has to be entered in PORT_ADR.
IN / OUT	identData	Variant	Area in the S7-CPU where the data written to the transponder is stored (global data block). 
OUTPUT	done	BOOL	TRUE if the last job has been completed without errors (for one cycle). FALSE if a new command is started.
	busy	BOOL	TRUE if the "LRfidIOL_Write" block is active. FALSE if the job was stopped or if an error occurred.
	error	BOOL	FALSE, if a command was completed without errors. TRUE if an error occurs when processing (for one cycle). Default value: FALSE
	status	DWORD	<ul style="list-style-type: none"> DW#16#00, if a command was completed without errors. In the case of an error (ERROR=TRUE) Hex value unequal zero (see Chapter 2.4). Remains on this value for one cycle.
	presence	BOOL	Presence bit. This bit is only set if a transponder is in the field of the reader.

4.4.4 FB "LRfidIOL_Antenna"

The FB "LRfidIOL_Antenna" library block switches the antenna of an RF200 IO-Link reader on or off. During normal operation, this command is not needed, because the antenna is always switched on after the reader is switched on. The following table shows the call interface of the library block FB "LRfidIOL_Antenna".

	Symbol	Data type	Explanation
INPUT	excute	BOOL	Enables the read/write job. Responds to a positive edge.
	adrTag	BOOL	TRUE: Switch antenna on. FALSE: Switching antenna off.
	hwId	HW_SUBMODULE	Hardware identifier of the IO-Link communication module. 
	portAdr	INT	Start address of the connected reader (PCT Tool)  Example: Start address 0.0, the value "0" has to be entered in PORT_ADR.
OUTPUT	done	BOOL	TRUE if the last job has been completed without errors (for one cycle). FALSE if a new command is started.
	busy	BOOL	TRUE if the "LRfidIOL_Read" block is active. FALSE if the job was stopped or if an error occurred.
	error	BOOL	FALSE, if a command was completed without errors. TRUE if an error occurs when processing the routine.
	status	DWORD	<ul style="list-style-type: none"> DW#16#00, if a command was completed without errors. In the case of an error (ERROR=TRUE) Hex value unequal zero (see Chapter 2.4). Remains on this value for one cycle.
	presence	BOOL	Presence bit. This bit is only set if a transponder is in the field of the reader.

You can find more details in the documents from the entry page of the application example at support.industry.siemens.com/cs/document/73565887.

5 Task

The hardware configuration from the "SCE_EN_012-201 Distributed hardware configuration with SIMATIC S7-1500 and ET 200SP on PROFINET" learning/teaching manual is to be extended by the "**CM 4xIO-Link**" IO-Link Master. The "**SIMATIC RF210R IO-Link**" RFID-Reader is to be connected to port 1 and commissioned there.

Place the IO-Link Master "**CM 4xIO-Link**" on slot 8. The server module is moved to slot 9 beforehand

Set the address range for the IO-Link Master starting at 10.

Module	Order number	Slot	Address range
CM 4xIO-Link	6ES7 137-6BD00-0AB0	8	10...41

Table1: IO-Link Master of the ET 200SP

Device	Order number	Port	Address range
RF210R IO-Link	6GT2 821-1BC32	1	10.0...41.7

Table2: Sensors on the IO-Link Master

Create a program with which the following user data can be read and written on an RFID-Transponder with the SIMATIC RF210R IO-Link reader:

Job number (data type: Integer)

Date (Data type: Date)

Time of day (Data type: Time_Of_Day)

Number_of_plastic_parts (data type integer)

The program is to be operated with a SIMATIC TP700 Comfort Panel.

6 Planning

The source project with CPU1516F and ET 200SP is to be retrieved.

The hardware is already specified for this project. Therefore, no selection is necessary.

The BaseUnit is also important for the extension of the ET 200SP by the **"CM 4xIO-Link"** IO-Link Master. This determines whether the potential is taken from the left terminal (dark BaseUnit), or whether a new power supply must be connected, thus creating a new potential group (light BaseUnit). The BaseUnit included in the Trainer packages are all of the type BU15-P16+A0+2D (6ES7193-6BP00-0DA0), so the light version is preset.

Before configuring the IO-Link system with the **"S7-PCT Port Configuration Tool"**, the hardware configuration is saved, compiled and loaded. The ET 200SP is assigned the PROFINET device name.

Any errors present can be detected during compilation and incorrect modules can be detected when the controller is started (*only possible when hardware is present and structured identically*).

The S7-PCT Port Configuration Tool is required to configure the IO-Link system with the **"RF210R IO-Link"** IO-Link device.

Reading and writing should be programmed in a function block (FB) "Read_Write_RFID_Data".

The blocks from the SIEMENS library **"IOL_READ-WRITE_DATA_LIB_V3.1"** are used to read and write the data on the RFID-Transponder.

These can only read and write data packets in the format array of the Byte type, whereby the data length of this raw data should correspond to the data length of the specified user data.

In addition, the 2 data blocks **"Data_Ident_Read"** and **"Data_Ident_Write"** are required for data management. Since both blocks contain the same data structures, these structures are created beforehand as raw data and user data user data types.

The "Serialize" and "Deserialize" blocks can be used for data transfer between raw data and user data.

For visualization and operation in the SIMATIC TP700 Comfort Panel, an **"RFID-Data"** image is created. There, the user data from the **"Data_Ident_Read"** and **"Data_Ident_Write"** data blocks are displayed, whereby the values can also be changed for writing.

If an RFID-Transponder is located in the area of the RF210R IO-Link RFID-Reader, the buttons for reading and writing the data are displayed.


The result is archived to back up the working version.

7 Structured step-by-step instructions

You can find instructions on how to carry out planning below. If you already have the necessary prior knowledge, the numbered steps are sufficient. Otherwise, simply follow the steps in the instructions.


7.1 Retrieving an existing project

- Before you can expand the project "SCE_EN_012-201 Distributed Hardware Configuration S7-1500 ET 200SP PN_R1807.zap15" from the chapter "SCE_EN_012-201 Distributed Hardware Configuration with SIMATIC S7-1500 and ET 200SP on PROFINET", you must retrieve it. To retrieve an existing project that has been archived, you must select the relevant archive with → Project → Retrieve in the project view. Confirm your selection with "Open".
(→ Project → Retrieve → Select a .zap archive ... → Open)




- The next step is to select the target directory where the retrieved project will be stored. Confirm your selection with "OK". (→ Target directory ... → OK)

- Save the opened project under the name 102-101_RFID-Sensor_RF210R_IO-Link.
 (→ Project → Save as ... → 102-101_RFID-Sensor_RF210R_IO-Link → Save)




7.2 ET 200SP: Inserting and configuring the IO-Link Master

→ Now open the device view of the "SortingStation01" device by opening the device configuration and select the "SortingStation01 [IM 155-6 PN HF]" device. (→ Device configuration → SortingStation01 [IM 155-6 PN HF])




→ Use drag & drop to move the server module to slot 9 and insert the "CM 4xIO-Link" module with the correct firmware from the catalog into slot 8.





(→ Server module_1 → Hardware catalog → Communication modules → IO-Link Master → CM 4xIO-Link → 6ES7 137-6BD00-0AB0 → V2.2)






→ In the properties of the IO-Link Master, select **"Enable new potential group (light BaseUnit)"** and set the IO addresses of the IO-Link Master to **"I 10...41"** and **"Q 10...41"** in the device overview. (→ CM 4xIO-Link_1 → Potential group → Enable new potential group (light BaseUnit) → Device overview → CM 4xIO-Link_1 → I address 10...41 → Q address 10...41)






7.3 Loading the hardware configuration and assigning device names


→ To save your project, select the  **Save project** button in the menu. The complete controller should then be loaded, as already described in the modules for hardware configuration .
(→  **Save project** → )



→ To obtain an overview of the assigned addresses within a project, you can click the  icon in the "Network view". (→ Network view →  Show address labels)





- In order for the controller, here the CPU1516F-3 PN/DP, to find the assigned PROFINET devices in the network, the device name must still be assigned to it. This is done by selecting the network that connects the devices in the "**Network view**" and then clicking on the  icon. (→  Assign device name)



Note:

- The IP addresses set in the project are automatically assigned to the devices by the controller when the communication connection is established.

- Online access must be correctly set in the dialog for assignment of the PROFINET device names. Each device can then be selected individually and filtered by devices of the same type. When a new device is connected the first time, the list must be updated again. (→ PROFINET device name: sortingstation01 → Type of PG/PC interface: PN/IE → PG/PC interface: here: Intel(R) Ethernet Connection I217-LM → ☒ Only show devices of the same type → )



Assign PROFINET device name.

Configured PROFINET device

PROFINET device name:

Device type:

Online access

Type of the PG/PC interface:

PG/PC interface:

Device filter

☒ Only show devices of the same type



☐ Only show devices with bad parameter settings

☐ Only show devices without names


Accessible devices in the network:


IP address	MAC address	Device	PROFINET device name	Status
0.0.0.0	28-63-36-67-F8-2A	ET200SP	—	⚠ No device name assigned


☐ Flash LED



 


Online status information:

 Search completed. 0 of 0 devices were found.

 Search completed. 1 of 2 devices were found.





- The correct device must be always be clearly determined by the MAC address printed on the device before the name is assigned. To check this, you can also have the LEDs on the device flash. (→  )





Accessible devices in the network:

IP address	MAC address	Device	PROFINET device name	Status
0.0.0.0	28-63-36-67-F8-2A	ET200SP	—	⚠ No device name assigned



→ The successful assignment of the PROFINET device name and the IP address (through the previously loaded CPU) should still be checked before the dialog is closed. (→

)




7.4 Inserting and configuring RF210R IO-Link RFID-Sensor with device tool (S7-PCT)

→ Now select the IO-Link Master **"CM 4xIO-Link_1"** with a right-click in the device view of the **"Sorting Station01"** device and start the **device tool (S7-PCT)** for IO-Link configuration. (→ Device view → SortingStation01 → CM 4xIO-Link_1 → Start device tool → S7-PCT → Start)



- Select the **"SIMATIC RF210R IO-Link"** RFID-Reader from the catalog of the S7-PCT software in the **"IO Link V1.1"** folder under **"SIEMENS AG" / "SIMATIC Ident"** and drag it to port 1 of the IO-Link Master. (→ IO Link V1.1 → SIEMENS AG → SIMATIC Ident → SIMATIC RF210R IO-Link)



Note:

- In the S7-PCT software, there is no option to save the configuration in the TIA Portal project. This happens automatically as soon as the S7-PCT software is closed again.
- If the **"SIMATIC RF210R IO-Link"** component is not available in the appropriate version in the catalog, you can use the → **Tools** menu to import it as → **IODD**. IODD V1.1 is available in the SCE Learn-/Training Document "SCE_EN_102-101_RFID-Sensor_RF210R_IO-Link_ET 200SP_S7-1500..." in the projects folder or using the following link: support.industry.siemens.com/cs/document/109750193 SIEMENS Product Support.

- Switch to the sub-folder "[1]SIMATIC RF210R IO-Link" and, in the "Parameters" tab there, change the "Mode" of the reader to "Acquisition user data".
 (→ [1] SIMATIC RF210R IO-Link → Parameters → Mode → Acquisition user data)

Parameters

Parameter	Value	Icon	Unit	Status	Help
Reader parameter (index 64)					
- Event message	Enabled			Initial value changed	Activating or deactivating event messages of the reader
- Mode	Acquisition user data			Initial value	Setting the operating mode
- Ready delay	No			Initial value	Ready signal is delayed so that consistency of the data
- Data holding time	Minimum			Initial value	Setting the data holding time. During his time process
- RF parameters	ISO default			Initial value	Selection whether the defaults or special RF parameters
IO link transmission speed (index 67)					
Transmission speed	230.4 Kbps			Initial value	IO link transmission speed
Direct parameter 1					
Reserved	0x00			Initial value	
Master Cycle Time	0x0			Initial value	
Min Cycle Time	0x0			Initial value	
M-Sequence Capability	0x0			Initial value	
IO-Link Version ID	0x11			Initial value	
Process Data Input Length	0x0			Initial value	
Process Data Output Length	0x0			Initial value	
Vendor ID 1	0x00			Initial value	
Vendor ID 2	0x00			Initial value	
Device ID 1	0x00			Initial value	
Device ID 2	0x00			Initial value	
Device ID 3	0x00			Initial value	
Reserved	0x00			Initial value	
Reserved	0x00			Initial value	
Reserved	0x00			Initial value	
Standard Command	0x00			Initial value	
System command					
Device Reset	Device Reset				Restart of the reader
Restore Factory Setting	Restore Factory Setting				Parameters will be set to the factory settings. Restart

Catalog

Search: Text search

Profile: V1.0 and V1.1

- IO Link V1.0
 - IO Link V1.1
 - Festo AG, Co. KG
 - SIEMENS AG
 - SIMATIC Ident
 - SIMATIC RF210R IO-Link
 - SIMATIC RF220R IO-Link
 - SIMATIC RF240R IO-Link
 - SIMATIC RF250R IO-Link
 - SIMATIC RF260R IO-Link
 - SIRIUS ACT Devices
 - SIRIUS Monitoring Relay
 - SIRIUS switching device
 - SIRIUS Temperature Monitoring Relay
 - STANDARD

Device

6GT2 821-1BC32

Product Name: SIMATIC RF210R IO-Link

Product Text: RFID-Reader, 13.56 MHz, ISO 15693, IP67, dimensions: M18 x 83 mm

Firmware Rev.:

Hardware Rev.:

Device Family: SIMATIC Ident


Release Date: 2017-07-17

IODD Filename: Siemens-RF210R-20170717-IODD1.1.xml


Ready

STEP 7 (Integrated) | Commissioning



- When you return to the folder "[Slot 8] CM 4xIO-Link_1" and select the "Addresses" tab there, you can select ☒ **Show PLC addresses** and ☒ **All ports** to see the process data of the RFID-Reader from the point of view of the PLC. (→ [Slot 8] CM 4xIO-Link_1 → Addresses → ☒ Show PLC addresses → ☒ All ports)



- Now select the folder "[Slot 8] CM 4xIO-Link_1" and click **Load with Devices**. The parameters are then written to the IO-Link Master and the RFID-Reader. (→ [Slot 8] CM 4xIO-Link_1 →)




→ Successful loading of the parameters is now displayed. **"Exit"** the **"S7-PCT"** tool and confirm the saving of the parameters with **"Yes"**. (→ File → Exit → Yes)




7.5 Creating data types for raw data and user data

→ Under PLC data types, create a "User_data_type_user_data" data type with the following structure. (→ PLC data types → Add new data type → User_data_type_user_data)





→ Under PLC data types, create a new "User_data_type_raw_data" data type with an array of the "Byte" type and a length of [1..10]. (→ PLC data types → Add new data type → User_data_type_raw_data)




7.6 Data blocks for the RFID-Read and write data

→ Create a "Data_Ident_Read" global data block. Under the use of the "User_data_type_raw_data" and "User_data_type_user_data" data types, define its structure as shown here. (→ Add new block → Data block → Global DB → Data_Ident_Read → Raw data → User_data_type_raw_data → User data → User_data_type_user_data)




- Create a "Data_Ident_Write" global data block. Under the use of the "User_data_type_raw_data" and "User_data_type_user_data" data types, define its structure as shown here. Save your project again. (→ Add new block → Data block → Global DB → Data_Ident_Write → Raw data → User_data_type_raw_data → User data → User_data_type_user_data →  Save project)





Note:

- When using a CPU with a firmware version older than V2.5, these two data blocks must not be optimized data blocks. In the properties of the blocks, this option must be deselected as follows:



7.7 Blocks from the IOL_READ_WRITE_DATA_LIB_V3.1 library

- Switch to the "**Global Libraries**" view and, right-click to select "**Retrieve library**" in order to retrieve the SIEMENS library "**IOL_READ_WRITE_DATA_LIB_V3.1**" (**LRfidIOL_V15**) with the blocks for communication with the SIMATIC RF210R IO-Link reader. (→ Global libraries → Retrieve library → IOL_READ_WRITE_DATA_LIB_V3.1 → Open)




Note:

- The library is available for the SCE Learn-/Training Document "SCE_EN_102-101_RFID-Sensor_RF210R_IO-Link_ET 200SP_S7-1500..." in the projects folder, but can also be downloaded from SIEMENS Product Support with the following link:
support.industry.siemens.com/cs/document/73565887.

7.8 "Read_Write_RFID_Data" function block

→ Create a "Read_Write_RFID_Data" function block with the function block diagram (FBD) programming language and open it. (→ Add new block → Function block → FUP → Read_Write_RFID_Data)




→ Define the local tags shown here in the "Read_Write_RFID_Data" function block. (→ Static
→ Temp)

102 101_RFID-Sensor_RF210R_IO-Link ▶ CPU_1516F [CPU 1516F-3 PN/DP] ▶ Program blocks ▶ Read_Write_RFID_Data [FB1]

Read_Write_RFID_Data

	Name	fault value	Retain	Accessible f...	Writa...	Visible in ...	Setpoint	Supervis...	Comment
1	▼ Input			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
2	<Add new>			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
3	▼ Output			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
4	<Add new>			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
5	▼ InOut			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
6	<Add new>			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
7	▼ Static			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
8	ReaDone	se	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
9	ReaBusy	se	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
10	ReaError	se	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
11	ReaStatus	#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
12	ReaPres	se	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
13	WriDone	se	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
14	WriBusy	se	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
15	WriError	se	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
16	WriStatus	#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
17	WriPres	se	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
18	HMI_Read	se	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		Trigger read via HMI-panel
19	HMI_Write	se	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>		Trigger write via HMI-panel
20	<Add new>			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
21	▼ Temp			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
22	Deserialize_POS			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
23	Deserialize_RET_VAL			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
24	Serialize_POS			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
25	Serialize_RET_VAL			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
26	<Add new>			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
27	▼ Constant			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
28	<Add new>			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		



- In the first network, call the **"LRfidiOL_READ"** block as a multiinstance from the previously retrieved global SIEMENS library **"LRfidiOL_V15"**. (→ Global libraries → LRfidiOL_V15 → Master copies → S7_1X00 → IOL_V11 → LRfidiOL_READ → Multiinstance → OK)




Note:

- When selecting the blocks from the SIEMENS "LRfidiOL_V15" library, note the version of the CPU used and the version of the SIMATIC RF210R IO-Link reader.

- Connect the "LRfidIOL_READ" block as shown here, whereby the wiring of the IN variable "hwId" is best done by a selection via drag & drop in the detailed view of the "standard tag table". You also connect the IN variable "identData" by selecting the "Data" array from the detailed view of the "Data_Ident_Read" data block using drag & drop.




- In the second network, call the **"Deserialize (V2.0)"** block from **"Instructions" / "Basic instructions" / "Move (V2.2)"** and connect it as shown here. (→ Instructions → Basic instructions → Move operations (V2.2) → Deserialize (V2.0))



Note:

- Note the version of the "Deserialize" instruction when selecting. This must be at least V2.0 in order to use optimized data blocks.


→ In the third network, call the **"Serialize (V2.0)"** block from **"Instructions" / "Basic instructions" / "Move (V2.2)"** and connect it as shown here. (→ Instructions → Basic instructions → Move operations (V2.2) → Serialize (V2.0))



Note:





- Note the version of the "Deserialize" instruction when selecting. This must be at least V2.0 in order to use optimized data blocks.


- In the fourth network, call the **"LRfidIOL_WRITE"** block as a multiinstance from the global SIEMENS library **"LRfidIOL_V15"** and connect it as shown here. (→ Global libraries → LRfidIOL_V15 → Master copies → S7_1X00 → IOL_V11 → LRfidIOL_WRITE → Multiinstance → OK)



Note:



- When selecting the blocks from the SIEMENS "LRfidIOL_V15" library, note the version of the CPU used and the version of the SIMATIC RF210R IO-Link reader.


- Now open the **"Main [OB1]"** block in FBD and call the **"Read_Write_RFID_Data"** block in the first network. Have the TIA Portal create the **"Read_Write_RFID_Data_DB"** instance data module. Now save the project by clicking "  Save project " before you load the **"CPU_1516F"** "  ". (→Main [OB1] → FBD → Read_Write_RFID_Data → OK →  Save project → )



7.9 Testing the application with the watch table_RFID

→ Create the "Watch table_RFID" shown here, with access to the user data in the two data blocks "Data_Ident_Read" and "Data_Ident_Write" as well as to the static tags "ReaPres" / "HMI_Read" / "WriPres" / "HMI_Write" via the "Read_Write_RFID_Data_DB" instance DB (→ Watch and force tables → Add new watch table → Watch table_RFID → Data_Ident_Read → Data_Ident_Write → Read_Write_RFID_Data_DB)

→ Test the reading and writing on the RFID-Transponder by first clicking on **"Monitor all"**  in the watch table. Now you can change the user data in the "Data_Ident_Write" data block with **"Modify once and now"** . If it is possible to read from or write to an RFID-Transponder, this is indicated in tag "WriPres==TRUE" or "ReaPres==TRUE". Now reading and writing can be tested with a positive edge at the "HMI_Read" or "HMI_Write" tag. (→





The screenshot displays the 'Watch table_RFID' configuration in the Siemens TIA Portal. The main table lists various data points for monitoring and modification. The table has columns for 'Addr...', 'Display format', 'Monitor value', 'Modify value', and 'Comment'.

Addr...	Display format	Monitor value	Modify value	Comment
1 // Read data from RFID-Transponder				
2 _Data_DB".ReaPres	Bool	TRUE		RFID-Transponder readable
3 _Data_DB".HMI_Read	Bool	TRUE	TRUE	Trigger read
4 d".User_data.Order_number	DEC+/-	12398		
5 d".User_data.Date	Date	D#2000-10-24		
6 d".User_data.Time	TIME_OF_DAY	TOD#15:30:00		
7 d".User_data.Number_of_plastic_parts	DEC+/-	5		
8 // Write data on RFID-Transponder				
9 _Data_DB".WriPres	Bool	TRUE		RFID-Transponder writable
10 _Data_DB".HMI_Write	Bool	FALSE	FALSE	Trigger write
11 e".User_data.Order_number	DEC+/-	12398	12398	
12 e".User_data.Date	Date	D#2000-10-24	D#2000-10-24	
13 e".User_data.Time	TIME_OF_DAY	TOD#15:30:00	TOD#15:30:00	
14 e".User_data.Number_of_plastic_parts	DEC+/-	5	5	
15				


The bottom status bar indicates: 'The project 102 101_RFID-Sensor_RF210r-...'.

7.10 Accessing data with a Panel TP700 Comfort


- Create a TP700 Comfort Panel in your project. (→ Add new device → HMI → SIMATIC Comfort Panel → "7" Display → TP700 Comfort → 6AV2 124-0GC01-0AX0 → Device name: Panel TP700 Comfort →  Start Device Wizard → OK)




→ In the HMI Device wizard, select your configured CPU 1516F as the communication partner and "Ethernet" as the interface. Confirm your selection by clicking **Next >>**.




→ In the "Screen navigation" section, create the screen structure displayed below with the corresponding screen names. Confirm your selection with a click on **Finish**.




→ Open the "**RFID-Data**" screen and delete the text in the background.




- In this screen, we need 2 "**Buttons**" with the labels "**Write**" and "**Read**". In each case, for "**Press**" create the "**Event**" "**SetBitWhileKeyPressed**" and link it to the "**HMI_WRITE**" and "**HMI_READ**" tags from the "**Read_Write_RFID_Data_DB**" instance DB. Add "**Text fields**" for description.




→ Animate the **"Visibility"** of the two buttons so that they are only displayed depending on the **"ReaPres"** and **"WriPres"** tags from the **"Read_Write_RFID_Data_DB"** instance DB.





→ Next, we create 8 "IO fields" by dragging & dropping the 4 tags in the "User data" structure from the "Data_Ident_Write" and "Data_Ident_Read" data blocks into our "RFID-Data" screen.




- Change the **"Type"** of the tags read to **"Output"** and adjust the **"Format"** of the **"IO fields"** so that the respective sizes can be sensibly displayed. Add **"Text fields"** for description.




→ Once the project has been saved "  Save project " and the **"TP700 Comfort"** panel has been loaded "  ", the visibility of the **"Read"** and **"Write"** buttons indicates that an RFID-Transponder has been detected by the sensor.

By clicking on **"Read"**, the values can be read on the transponder and displayed below it. The values to be written can be entered in the IO fields under **"Write"** and then written to the RFID-Transponder by clicking on **"Write"**.




7.11 Archive the project


→ To archive the project, select the → "Archive ..." command in the → "Project" menu.



→ Confirm the prompt to save the project if needed with → "Yes".



→ Select a folder where you want to archive your project and save it as a "TIA Portal project archive" file type. (→ "TIA Portal project archive" → "SCE_EN_102-101_RFID-Sensor_RF210R_IO-Link..." → "Save")



7.12 Checklist – step-by-step instructions

The following checklist helps trainees/students to independently check whether all steps of the step-by-step instruction have been carefully completed and enables them to successfully complete the module on their own.

No.	Description	Checked
1	Program changes successfully performed in the CPU 1516F	
2	CPU 1516F successfully compiled without error message	
3	CPU 1516F successfully downloaded without error message	
4	Loading of IO-Link Master CM 4xIO-Link and RFID-Sensor RF210R IO-Link with device tool (S7-PCT) successfully completed	
5	Process visualization for the Touch Panel TP700 Comfort successfully created	
6	Touch Panel TP700 Comfort successfully compiled without error message	
7	Touch Panel TP700 Comfort successfully downloaded without error message	
8	Writing of user data with panel on RFID-Transponder successfully completed	
9	Reading of user data with panel from RFID-Transponder successfully completed	
10	Project successfully archived	

8 Exercise

8.1 Task – Exercise

In this exercise, the function block (FB) **"Read_Write_RFID_Data"** is to be created and converted to a library-compatible block and a **"DATE_TIME"** function created in which the local time of the CPU1516F is read out.

The following parameters should be available when the library-compatible block is called:

Input	Data type	Comment
adrTag	Word	Start address of the data to be read on the transponder
hwId	HW_SUBMODULE	Hardware identifier of the IO-Link communication module
length	Word	Length of the data that is read from transponder
portAdr	Int	Start address of the connected reader (PCT Tool)
Execute_Data_Read	BOOL	Read job activated at positive edge
Execute_Data_Write	BOOL	Write job activated at positive edge
Output		
Error	Bool	FALSE, if a command was completed without errors; TRUE, if an error occurs when processing
InOut		
Ident_Data_Read	"User-defined data type_User data"	Area in the S7-CPU where the read data is stored
Ident_Data_Write	" User-defined data type_User data "	Area in the S7-CPU where the data written to the transponder is stored

Update the function block (FB) **"Read_Write_RFID_Data"** call in the "Main" organization block call and connect the parameters.

In the Touch Panel TP700 Comfort, change the tag access in the **"RFID-Data"** screen of the 2 **"Buttons"** for the input tags **"Execute_Data_Read"** and **"Execute_Data_Write"** from the **"Read_Write_RFID_Data_DB"** instance DB.

In the **"DATE_TIME"** function, the current date and also the current time are to be made available as **"OUTPUT"** parameters and written to the user data of the **"Data_Ident_Write"** data block when the function is called.

Finally, the operator only has to enter the order number and number of plastic parts at the HMI panel.

8.2 Planning

Plan the implementation of the task on your own.

Note:

- Refer to the manuals or to Module SCE_EN_032-200 FB- Programming about library-compatible blocks.
- Refer to the online help to learn how to use the extended instructions of SIMATIC S7-1500. Especially in terms of date and time.
- Also note the time settings in the hardware configuration of the CPU1516F.

8.3 Checklist – Exercise

The following checklist helps trainees/students to independently check whether all steps of the exercise have been carefully completed and enables them to successfully complete the module on their own.

No.	Description	Checked
1	Compiling successful and without error message	
2	Download successful and without error message	
3	Display of the current date and time on the HMI panel in the "RFID-Data" screen	
4	Project successfully archived	

9 Additional information

You can find additional information as an orientation aid to familiarize yourself or deepen your knowledge, for example: Getting Started, videos, tutorials, apps, manuals, programming guidelines and trial software/firmware, at the following link:

[siemens.com/sce/rfid](https://www.siemens.com/sce/rfid)

Preview "Additional information"

Getting Started, Videos, Tutorials, Apps, Handbücher, Trial-SW/Firmware

- Videos RFID-Systeme
- Applikationen RFID-Systeme
- Forum RFID-Systeme
- Technische Dokumentation RFID-Systeme
- Industry Online Support App
- Website Industrielle Identifikation
- Website SIMATIC RFID

Additional information

Siemens Automation Cooperates with Education
[siemens.com/sce](https://www.siemens.com/sce)

SCE Learn-/Training Document
[siemens.com/sce/module](https://www.siemens.com/sce/module)

SCE Trainer Packages
[siemens.com/sce/tp](https://www.siemens.com/sce/tp)

SCE Contact Partners
[siemens.com/sce/contact](https://www.siemens.com/sce/contact)

Digital Enterprise
[siemens.com/digital-enterprise](https://www.siemens.com/digital-enterprise)

Industrie 4.0
[siemens.com/future-of-manufacturing](https://www.siemens.com/future-of-manufacturing)

Totally Integrated Automation (TIA)
[siemens.com/tia](https://www.siemens.com/tia)

TIA Portal
[siemens.com/tia-portal](https://www.siemens.com/tia-portal)

SIMATIC Controller
[siemens.com/controller](https://www.siemens.com/controller)

SIMATIC Technical Documentation
[siemens.com/simatic-docu](https://www.siemens.com/simatic-docu)

Industry Online Support
support.industry.siemens.com

Industry Mall catalog and ordering system
mall.industry.siemens.com

Siemens
Digital Industries
P.O. Box 4848
90026 Nuremberg
Germany

Errors excepted and subject to change without prior notice.
© Siemens 2019

[siemens.com/sce](https://www.siemens.com/sce)