

SCE Training Curriculum

Siemens Automation Cooperates with Education (SCE) | 09/2015

PA Module P03-02 SIMATIC PCS 7 – Vertical Integration with OPC

Cooperates with Education	SIEMENS
Automation	

Matching SCE Trainer Packages for these curriculum

- SIMATIC PCS 7 Software block of 3 packages Order No. 6ES7650-0XX18-0YS5
- SIMATIC PCS 7 Software block of 6 packages Order No. 6ES7650-0XX18-2YS5
- SIMATIC PCS 7 Software Upgrade block of 3 packages
 Order No. 6ES7650-0XX18-0YE5 (V8.0 → V8.1) or 6ES7650-0XX08-0YE5 (V7.1 → V8.0)
- SIMATIC PCS 7 Hardware Set including RTX Box Order No. 6ES7654-0UE13-0XS0

Please note that these trainer packages may be replaced with subsequent packages. An overview of the available SCE packages is provided at: <u>siemens.com/sce/tp</u>

Continuing education

For regional Siemens SCE continuing education, contact your regional SCE contact partner. <u>siemens.com/sce/contact</u>

Additional information relating to SIMATIC PCS 7 and SIMIT

In particular, Getting Started, videos, tutorials, manuals and programming guide. <u>siemens.com/sce/pcs7</u>

Additional information relating to SCE

siemens.com/sce

Note on Usage

The training curriculum for the integrated automation solution Totally Integrated Automation (TIA) was prepared for the program "Siemens Automation Cooperates with Education (SCE)" specifically for training purposes at public educational and R&D facilities. Siemens AG is not liable for the contents.

This document may only be used for initial training on Siemens products/systems. This means it may be copied entirely or partially and handed to trainees for use within the scope of their training. Passing on or copying this document and communicating its contents is permitted within public training and continuing education facilities for training purposes.

Exceptions require written permission by Siemens AG. Contact person: Roland Scheuerer roland.scheuerer@siemens.com.

Violators are subject to damages. All rights including translation rights are reserved, particularly in the event a patent is granted or a utility model or design is registered.

Usage for industrial customer courses is explicitly not permitted. We do not agree to the commercial utilization of these documents.

We would like to thank the Technical University Dresden, particularly Prof. Dr. Leon Urbas and Annett Krause, MS, as well as the Michael Dziallas Engineering Corporation and those who provided support in preparing this SCE training document.

VERTICAL INTEGRATION WITH OPC

TRAINING OBJECTIVE

In this chapter, the students learn to integrate automation systems from diverse manufacturers into higher level programs of the plant control level. The required fundamentals for setting up OPCs and the method of functioning as well as the integration possibilities by means of PCS 7 are explained.

THEORY IN BRIEF

OLE for Process Control (OPC) provides a standard mechanism for communication with a variety of data sources. It makes no difference in this case whether these sources are machines in your factory, or a database in your control center. OPC is based on the OLE/COM technology by Microsoft.




Figure 1: Integration of the IT world into automation systems [3]

By means of an OPC server, data can be exchanged with external systems without knowledge of the topology and a PCS 7 OS installation being required.

From the view of the user programs generated in higher level programming languages such as C++ and Visual Basic, OPC is a bridge to the process data and the device data of the automation systems. For the device manufacturers, the development of an OPC server is necessary instead of special drivers. For software developers it is of advantage: applications can be written independent of the device. Users in turn have more freedom regarding the selection of devices and software products [1].

THEORY

INTRODUCTION

OPC provides a standardized, open and manufacturer-independent software interface for integrated data communication between automation systems and MS Windows applications with OPC capability. OPC has developed into a de-facto standard for interfacing automation systems by different manufacturers with higher level programs of the plant control level for

- Process visualization (monitoring of individual product lines with cross data traffic)
- Integrated management (ordering, quality control, maintenance, material management, production planning)

The software interface OPC is based on the Windows technologies COM (Component Object Model) and DCOM (Distributed Component Object Model). OPC XML on the other hand is based on the internet standards XML, SOAP and http. COM is the Microsoft protocol standard for communication between objects that are located on one computer but in different programs. With DCOM, COM was expanded with the capability to access objects beyond computer boundaries. This basis makes possible standardized data exchange between applications from industry, office and manufacturing. Communication via DCOM is limited to local networks. Data exchange by means of XML uses the protocol SOAP (Simple Object Access Protocol). SOAP is an XML based protocol that is independent of the platform. With SOAP, applications on the Internet or in heterogeneous computer networks can communicate with each other by means of HTTP (HyperText Transfer Protocol).

The OPC Foundation defined the standard for the OPC interface. Leading corporations in industry automation comprise the OPC Foundation. The OPC servers of the OS system support the following specifications:

- OPC Data Access 1.0, 2.05a and 3.0
- OPC XML Data Access 1.01
- OPC Historical Data Access 1.20
- OPC Alarm & Events 1.10

CLIENT-SERVER PRINCIPLE

OPC communication is based on the client server principle (refer to

Figure 2). The client takes the initiative and makes a request to the server (service provider). The server replies, executes or supplies. The connection structure needed for this always emanates from the OPC client. The advantage of such a communication scheme is that only the clients have to "know" the server.

The OPC server can access the process data of the automation system.

OPC Server

The OPC software component that provides data when an OPC client requests it is called **OPC server**. The server has to be installed on the PC since OPC specific entries are required in the Windows registry. "Upwards", the OPC server supports the interface specification Data Access; "downwards" it is connected through a lower level communication network with the connected automation system as the actual data source.




Figure 2: Client-server model [1]

OPC Client

OPC components that use an OPC server as data source are called **OPC clients**. An OPC client is, as a rule, part of the user program that has to be configured. To this end, two OPC interfaces are available:

- The *custom interface* (customer specific interface) for programming languages that address interfaces with the function pointer principle, such as C/C++
- The *automation interface* for programming languages that address interfaces with object names, such as Visual Basic

OPC SPECIFICATION

OPC Data Access (OPC DA)

Data Access is an OPC specification used to access process data by means of variables. OPC servers for Data Access manage the process variables and the different access capabilities to these variables. This allows the OPC server:

- To read the value of one or several process variables
- To change the value of one or several process variables by writing a new value
- To monitor the value of one or several process variables
- To signal value changes

Process variables are place holders for values that currently have to be determined. The OPC specification defines the interface between client and server programs for managing the process data. Data Access servers make the transparent access to the most varied data sources (for example, temperature sensor) and data sinks (for example, control systems) possible for one or several Data Access clients. These data sources and data sinks can be located on IO cards inserted directly into the PC, but they can also be on any device such as controllers, input/output modules, etc., that are connected by means of serial connections or field busses. A Data Access client can also access several Data Access servers at the same time.

Data Access clients can be very simple Excel sheets or extensive programs (for example, Visual Basic). Data Access clients in turn can be part of larger programs.

OPC Data Access Class Model

When the client accesses data, the hierarchical class model of Data Access assists in adapting the time effort and the result of the content to the current requirements of the application. Data Access differentiates three classes:

- OPC server
- OPC group
- OPC item




Figure 3: Class model of the Data Access Interface [2]

The client application uses COM calls of the operating system only to generate an object of the class OPC server. The other objects are generated by means of corresponding OPC methods of the class OPC server or lower level classes.

The highest class is the **OPC server**. Every OPC server belongs to this class. This class represents the access for all other services of the Data Access server. With the aid of class specific attributes, information about the status, the version and (optional) the name space of the available process variables can be obtained. Objects of the class OPC server manage the instances of the lower level class OPC Group.

The class **OPC group** is directly subordinated to the class OPC server and structures the process variables utilized by the OPC server. The OPC client is able to use several objects of this class simultaneously. With the aid of the objects of OPC group, the client can generate useful units of process variables and perform operations with them. For example, all process variables of a screen page of the operator interface can be combined into one group. The class OPC group defines methods that can be used to read and write the values of the process variables.

The class **OPC item** represents the actual process variable and allows for polling individual data. Each variable is an element (item) in the OPC server's name space and is identified with an item ID. The item ID is specified by the manufacturer of the server and has to be unique within the server's name space. Each value has the following properties:

– Value

The last recorded value of the variable

- Quality

How meaningful is the value. If the quality is good, it was possible to determine the value with surety

Timestamp

Point in time when the current value of the variable was determined. With each value change indicated to the client, the time stamp is updated. If the value of the variable does not change, the timestamp remains the same also.

Variables have to be specified when the OPC interface is called to obtain process values. By indicating variables, the client is able to request the needed values from the server. The client has to sign up every requested variable at the server to specify the variables that are to be read. Variables can be read and written synchronously as well as asynchronously.

The client can transfer the monitoring of variables to the server. If the value of a variable changes, the server sends a corresponding message to the client. The variables provided by the OPC server can be subdivided into:

- Process variables

represent measured and control variables of input/output devices

- Control variables

Using these variables triggers certain supplementary services, such as the transmission of pass words

Information variables

These variables are made available by the communication system and by the OPC server and provide information about the state of connections, devices, etc..

Below a few examples of the variables of an OPC Data Access server:

- Control variables of a PLC
- Data of a measurement data acquisition system
- Status variables of the communication system

OPC eXtensible Markup Language DA (OPC XML DA)

OPC XML is a standard that makes possible communication with a platform-independent protocol over the Internet. The client is no longer tied to a Windows environment (DCOM). With the HTTP protocol and the SOAP interface, other operating system -for example LINUX- can monitor and exchange OPC data via the Internet.

SOAP provides a simple and transparent mechanism for exchanging structured and typified information between computers in a decentralized, distributed environment. SOAP is a basis for XML based information exchange.

Data access by means of OPC XML has a functional scope based on OPC Data Access. Change controlled feedback regarding data changes as in the case of DCOM interfaces is not provided for OPC XML because of the lose internet connection.

Accessing methods directly from the Internet represents a considerable security risk. For that reason, SOAP uses exclusively the Internet http channel (HTTP = Hyper Text Transfer Protocol) that can be managed easily with a firewall.




Figure 4: Data transfer with HTTP [2]

OPC Alarms & Events (OPC A&E)

OPC Alarm & Events is an additional specification for transmitting process alarms and events. Events are special states in the process that have to be indicated to the recipient. The OPC specification defines three types of events for this:

Condition related events

They indicate the state transitions defined in the OPC state model and are tied to defined conditions

Tracking events

They indicate process changes; for example, when a user changes the setpoint of a controller

Simple events

They indicate all other stateless events; for example, the failure of a system component

Alarms & Events servers are used for the following, for example:

- Detecting events for example, reactor level reached
- Determining the state of an event product tank full
- Confirming an event reactor level reached detected,
- Monitoring the confirmation the confirmation is monitored by the reactor alarm indicator; the alarm was detected; the warning signal can be switched off

New events can be indicated without confirmation also. By means of filter criteria, the OPC client sets the events that are indicated to the OPC client. All events corresponding to the set filter criteria have to be forwarded by the originator of the event up to the user. This differentiates Alarms & Events from Data Access. For variable monitoring, only the value changes in the specified time frame are indicated.

The OPC specification defines the syntax of the interface for message receipt. The manufacturer of the OPC server specifies the event types that a server provides.

OPC SERVER OF SIMATIC NET

The open OPC interface is the central interface of the products on the PG/PC of SIMATIC NET. The OPC server of SIMATIC NET supports all communication protocols and services that the communication modules make available.

The OPC server of SIMATIC NET supports for all protocols the interface specification OPC Data Access. For protocols that have mechanisms for transmitting events (S7 communication) OPC Alarms & Events is supported also.

The OPC server of SIMATIC NET makes possible the access to the industrial communication networks PROFIBUS and Industrial Ethernet of SIMATIC NET. It provides OPC clients with the values of process variables or indicates events from the peer device. To this end -with the aid of the protocol software and the communication processor of SIMATIC NET- it accesses the peer devices via the communication network (refer to).

	OPC client (for example, operator control and monitoring system)					
OPC server for	OPC interface					
Data access	Alarms & Events					
Protocol software f	rom SIMATIC NET					
Communications proces	ssor from SIMATIC NET					
		Communication network from SIMATIC NET				

Figure 5: OPC Server for SIMATIC NET with OPC Client [2]

OPEN PCS 7

OpenPCS 7 was developed for use on multi-user systems. By means of a separate PC station with OpenPCS 7 (OpenPCS 7 station), data can be exchanged with external systems without knowledge of the topology and without a PCS 7 OS installation being necessary. This server collects from existing OS server systems the data via OPC and makes it available in a concentrated form. For that reason, OpenPCS 7 can be used exclusively on multi-user systems.

OpenPCS 7 can be used for data exchange with the following levels:

- Automation level
- Plant control and production level
- MES level (Manufacturing Execution Systems)
- ERP level (Enterprise Resource Planning)

LITERATURE

- [1] Wellenreuther, G.: Zastrow, D. (2009) Automatisieren mit SPS (4. Auflage). Vieweg + Teubner. (Automating with PLC)
- SIEMENS (2010): SIMATIC NET: Industrial Communication with PG/PC Volume 1 -Basics System Manual. C79000-G8976-C172-09. (http://support.automation.siemens.com/WW/view/en/42783968)
- [3] SIEMENS (2015): Process Control System PCS7: Engineering System (V8.1). A5E32712311-AC. (http://support.automation.siemens.com/WW/view/en/90663380)

STEP BY STEP INSTRUCTIONS

TASK

The example below shows how to access variables in the OS from Microsoft Excel through OPC. In these step by step instructions, select the level of Reactor R001 to access them.

The settings necessary for this are made in an Excel file. The required macros already exist in the Excel file and are started automatically with the correct settings.

Detailed knowledge regarding macro-programming is not assumed in this training module nor is it provided. Refer to the manuals and technical literature on Microsoft Excel.

To diagnose the availability of the OPC server of WinCC, the software OPC Scout V10 of SIMATIC NET is used.

TRAINING OBJECTIVE


In this chapter, the student learns:

- Diagnosis of the local OPC servers with the OPC Scout V10
- Display of variables available via OPC in OPC Scout V10
- Settings in Excel for OPC access to the variables provided in WinCC
- Test of a Microsoft Excel application with access to variables of WinCC via OPC

These instructions are based on the project 'PCS7_SCE_0301_Ueb_R1504_en.zip' and the Microsoft Excel file 'PCS7_SCE_0302_OPC_Template_R1305_en.xls'.

PROGRAMMING

 After opening the exercise project from chapter "Advanced Layouts for UIs P03-01", start PLCSIM and in the 'Plant View' Compile and Download Objects of the project is opened. (→ SCE_PCS7_Prj → PLC → Compile and Download Objects)




 Before you 'Start' the compilation, make sure the S7-PLCSIM is in STOP mode. Everything is compiled and downloaded regarding the charts. Regarding the OS, compile without 'Memory reset'. (→ Start)


Compile and Download Objects	-			X
Selection table:				
Objects	Status	Operating Mode	Compile	Download
E-By PCS7_SCE_Prj			V	
			×	
00 Hardware	compiled		1	v
E- S CPU 414-3 DP		STOP	4	×
Blocks				
Charts	downloaded		✓	✓
Connections	compiled		1	V
OS			×	
Du Configuration	compiled		✓	
E- WinCC Appl.			1	
Connections	downloaded		✓	
S(1)		Not open	 Image: A start of the start of	
Settings for Compilation/Download Edit Desting for Compilation/Download Desting for Compilation/Desting for Compila	View L		Objects	Deselect All
Compile only I Do not load if compilation error is detected Start Close				Help

3. Next, set S7 PLCSIM to the 'RUN' mode and open WinCC.

 $(\rightarrow SIMATIC PC Station(1) \rightarrow WinCC Appl \rightarrow OS(1) \rightarrow Open Object)$



4. Then, in WinCC, activate Runtime.



5. After Runtime is completely powered up, start 'OPC Scout V10'.

 $(\rightarrow$ Start \rightarrow Siemens Automation \rightarrow SIMATIC \rightarrow SIMATIC NET \rightarrow OPC Scout V10)

Programs (1) ———	
OPC Scout V10	
See more results	
- see more results	
opc scout	× Shut down +
	,
1	

 In the OPC Scout V10, diagnostic data for the different OPC servers of the local PC is displayed. If it is not possible to set up the connection to a certain server, this is indicated as an error.

(unknown) - Siemens AG - OPC Scout V10		
File Edit View Server Explorer Workbook To	ols Window Help	
I. I		
🚆 Server Explorer		→ # X
1		
E Local COM server	Server information Items	
CCOPC.UAWrapper		
E-	ID	Value
🗈 📑 OPC.SimatidNET	Status	
DPC.SimaticNet.AE	Status	The server is running normally.
OPC.SimaticNET.DP	Status Start time	05/13/2015 02:16:57.173 PM
OPC.SimaticNET.PD	Yersion	3.9.10202
DPC.SimaticNetAlarms	Tendor information	SIMATIC WinCC OPC-Server DataAccess V3.9 Copyright (C) 2004-2014 Siemens AG; OPC DA 2.05A/3.00 Specification
OPC.SimaticNetAlarmsSNMP OPC.SimotionAlarms	Capability features	
OPC.Simotonalarms OPCServer.Simit	Capability reatures	
D- CPCServer.WinCC	Supported interfaces	OPC DA 2.0/ OPC DA 3.0
C QLOCALMACHINE::	The Locales	de-DE/ en-US
E Interne Variablen		
Liste aller Strukturinstanzen	Connection defaults	
🗄 🦳 Liste aller Variablen	Server name	OPCServer.WinCC
- SIMATIC S7 Protocol Suite	ClsID	{75D00BBB-DDA5-11D1-B944-9E614D000000}
🗄 🛄 Industrial Ethernet	🚰 Host name	localhost
🖲 🔄 Industrial Ethernet (II)	Protocol	COM/DCOM
_ Workbook	DA view 1	×
토 등 등 표 🖂 🔍	Monitoring Ol	N 💽 Generate values ON 🔲 Read 🖋 Write
Project 'New project'		
🖯 🦢 Server		
COM server	ID	Display name Type Access rights Time stamp (UTC) Value Quality Result
XML server		
UA server		
DA view 1	•	
UTC • : 5/13/2015 12:18:30 PM		

7. The WinCC server is called 'OPCServer.WinCC'. Below this server, a file structure can be opened down to the CFC blocks that allow monitoring. In this example, we selected the block 'Monitor_A1T2L001' to display the level of Reactor R001. (→ OPCServer.WinCC → @LOCALMACHINE → SIMATIC S7 Protocol Suite → TCP/IP → S7 Program →A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/ Monitor_A1T2L001)

Edit View Server Explorer Workbook To	als Window Help					
	※面面(X)日間・					
rver Explorer						-
OPCServer.WinCC A	Items Properties					
🖻 🔄 @LOCALMACHINE::		ID				
Internal tags				Type	Access rights	Item name
E List of all structure instances		action/reactor\$R001/A1T2L001/Monitor_/ action/reactor\$R001/A1T2L001/Monitor /		string	RW RW	A1_multipurpose_pla A1_multipurpose_pla
E List of all tags		action/reactor\$R001/A1T2L001/Monitor_/		float	RW/	A1_multipupose_pla
Imatic S7 Protocol Suite		action/reactor\$R001/A1T2L001/Monitor_/		uint	RW/	A1_multipurpose_pla
Industrial Ethernet	A1 multipurpose plant/T2 re	action/reactor\$R001/A1T2L001/Monitor_/	ATT2L001.EventRaw#1	uint	B	A1_multipurpose_pla
🗄 🦢 Industrial Ethernet (II) 💡		action/reactor\$R001/A1T2L001/Monitor		int	R/w'	A1_multipurpose_pla
🕀 🔄 MPI		action/reactor\$R001/A1T2L001/Monitor_A		uint	R	A1_multipurpose_pla
B- in Named Connections		action/reactor\$R001/A1T2L001/Monitor_/		bool	RW/	A1_multipurpose_pla
PROFIBUS		action/reactor\$R001/A1T2L001/Monitor_/		uint	RW	A1_multipurpose_pla
PROFIBUS (II)		action/reactor\$R001/A1T2L001/Monitor_/ action/reactor\$R001/A1T2L001/Monitor_/		bool	RW RW	A1_multipupose_pla A1_multipupose_pla
C Siet PLC		action/reactor\$H001/A112L001/Monitor_/ action/reactor\$R001/A1T2L001/Monitor /		bool	HW/ RW/	A1_multipurpose_pla A1_multipurpose_pla
🗷 🦢 Soft PLC		action/reactor\$R001/ATT2L001/Monitor./		bool	R/w'	A1_multipupose_pla
E TCP/IP		action/reactor\$R001/A1T2L001/Monitor_/		uint	RW/	A1_multipurpose_pla
🗄 - 🤐 S7\$Program(1)	A1_multipurpose_plant/T2_re	action/reactor\$R001/A1T2L001/Monitor	A1T2L001.0pSt_In#Jump	string	B	A1_multipurpose_pla
A1_multipurpose_plant	A1_multiputpose_plant/T2_re	action/reactor\$R001/A1T2L001/Monitor_/	A1T2L001.0pSt_In#OS_Text	string	R	A1_multipurpose_pla
A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/		uint	RW/	A1_multipurpose_pla
A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/		uint	RW/	A1_multipurpose_pla
B- A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/		uint	RW	A1_multipurpose_pla
A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor./ action/reactor\$R001/A1T2L001/Monitor./		float	RW/ RW/	A1 multipurpose pla A1_multipurpose_pla
B- A1_multipurpose_plant		2_reaction/reactor\$R001/A1T2L001/Monito_			RW/	A1_multipupose_pla
A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor		float	RW	A1_multipupose_pla
B A1_mutipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/		uint	RW/	A1_multipurpose_pla
A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor		float	RW	A1_multipurpose_pla
B A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_A		uint	RW/	A1_multipurpose_pla
B- A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/		float	RW/	A1_multipupose_pla
A1_mutipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/		float	RW/	A1_multipurpose_pla
B- A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/		float	R₩	A1_multipurpose_pla
A1_multipurpose_plant		2_reaction/reactor\$R001/A1T2L001/Moni action/reactor\$R001/A1T2L001/Monitor_/		. string short	R RW	A1_multipurpose_pla A1_multipurpose_pla
B- A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor /		string	R	A1_multipurpose_pla
A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor A		float	RW/	A1_multipurpose_pla
B- A1_multipurpose_plant		2 reaction/reactor\$R001/A1T2L001/Moni			RW/	A1_multipupose_pla
A1_multipurpose_plant	A1_multipurpose_plant/T2_re	action/reactor\$R001/A1T2L001/Monitor_/	AT2L001.PV_WL_Lim	float	RW/	A1_multipurpose_pla
E A1_multipurpose_plant		2_reaction/reactor\$R001/A1T2L001/Moni			R/w'	A1_multipurpose_pla
A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/		string	R	A1_multipurpose_pla
E A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/		string	R	A1_multipurpose_pla
A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/ action/reactor\$R001/A1T2L001/Monitor /		bool	RW/	A1_multipurpose_pla A1_multipurpose_pla
E A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/ action/reactor\$R001/A1T2L001/Monitor_/		uint ficat	RW	A1_multipurpose_pla A1_multipurpose_pla
A1_multipurpose_plant		action/reactor\$R001/A112L001/Monitor_/ action/reactor\$R001/A112L001/Monitor /		uint	RW/	A1_multipupose_pla A1_multipupose_pla
E A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor /		ubxte	RW/	A1_multipupose_pla
A1_multipurpose_plant		action/reactor\$R001/A1T2L001/Monitor_/		uint	RW/	A1_multipurpose_pla
E- 🗀 A1 multipupose plant		action/reactor\$R001/A1T2L001/Monitor_/		uint	RW/	A1_multipurpose_pla
A1_multipurpose_p		action/reactor\$R001/A1T2L001/Monitor_A		uint	RW	A1_multipurpose_pla
Al millioumore r	A1_multipurpose_plant/T2_re	action/reactor\$R001/A1T2L001/Monitor_/	A1T2L001.UserStatus	ubyte	RW/	A1_multipurpose_pla
m F	1					
orkbook 🛛 🖛 🕂 🗙	SDA view 1					
55 # 2 3	and out of a					
	Monitoring ON	Generate values ON	I Rea	۱ 🖌 او	Write	
oject 'New project'						
Server				(1.1.m		
- COM server	ID	Display name Type	Access rights Time st	amp (UTC)	¥alue	Quality R
- De XML server						
- 🔄 UA server						
Views	<	111				
CA view 1						


8. From the data of this monitoring block, we want to monitor the input 'PV#Value'. For this reason, drag it to the lower area of 'DA view 1'.

(→A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001 PV#Value)

unknown) - SIEMENS AG - OPC Scout V10				
Edit View ServerExplorer Workbook Ti	iols Window Help			
	X 油 市民 自果。			
erver Explorer	s - a - a - a - a - a - a - a - a - a -			- 0
or yor capitor of				
- John Contraction - A Contrac				
B 📑 OPCServer.WinCC A	Rems Properties			
ecochemonine	ID	Туре	Access rights	Item name
List of all structure instances	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.B atchID	uint	RW	A1_multipurpose_plan
E- I List of all tags	A1_multiputpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.B atchN ame	string	RW.	A1_multipurpose_plan.
E- SIMATIC S7 Protocol Sute	A1_multipurpore_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.D eadB and	float	RW.	A1_multipurpose_plan
🖲 🦳 Industrial Ethernet	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.DeadBand#0.p_Level A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.EventR.aw#1	uint uint	RW R	A1_multipurpose_plan A1_multipurpose_plan
Industrial Ethernet (II)	A1_multiputpote_plant/12_reaction/reactorpriou1/A112L001/Monitor_A112L001.EventHaW#1 A1_multiputpote_plant/T2_reaction/reactorpriou1/A112L001/Monitor_A112L001.EventHaW#1	int	BW	A1_multipurpose_plan
🕀 🥁 MPI	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001 EventTrans#1	uint	B	A1_multipurpose_plan.
Named Connections	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.MS_ReIDp	bool	RW	A1_multipurpose_plan.
B PROFIBUS	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.MS_RelD p#0 p_Level	uint	RW	A1_multipurpose_plan
🖲 🥁 PROFIBUS (II)	A1_multipurpose_plant/T2_reaction/teactordR001/A1T2L001/Monitor_A1T2L001.0 n0p	bool	RW.	A1_multipurpose_plan
B- Slot PLC	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.0n0p#0.p_Level A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.0n0p#0.p_Level	uint bool	RW RW	A1_multipurpose_plan.
E- 🔄 Soft PLC	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.0osAct#Value A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.0 os0.p	bool	RW	A1_multipurpose_plan. A1_multipurpose_plan.
E- 🛄 TCP/IP	A1_multiputpose_plant/12_reaction/reactorsPr001/A112L001/Monitor_A112L001.0 cst0.p A1_multiputpose_plant/T2_reaction/reactorsPr001/A112L001/Monitor_A112L001.0 cst0.p	uint	BW	A1_multipurpose_plan.
	A1_multipurpose_plant/T2_reaction/reactor@R001/A1T2L001/Monitor_A1T2L001.0pS(_In#Jump	string	B	A1_multipurpose_plan.
A1_multipurpose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.0pSt_In#OS_Text	string	R	A1_multipurpose_plan.
E A1_multipurpose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.0 pSt_0 ut	uint	RW	A1_multipurpose_plan.
B- A1_mutipupose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.0S_PermLog	uint	RW/	A1_multipurpose_plan.
A1_mutipupose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.0S_Perm0.ut	uint float	RW RW	A1_multipurpose_plan.
H Al_multipurpose_plant	A1 multipurpose plant/T2 reaction/reactor/\$R001/A1T2L001/Monitor A1T2L001 PV#Value A1_multipurpose_plant/T2_reaction/reactor/\$R001/A1T2L001/Monitor_A1T2L001.PV_AH_Lim	float	BW	A1 multipurpose plan. A1_multipurpose_plan.
B- A1_multipurpose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_AH_Lim#Op_Lev	uint	BW	A1_multipurpose_plan.
B· A1_mutipupose_plant	A1_multipurpose_plant/T2_reaction/reactordR001/A1T2L001/Monitor_A1T2L001.PV_AL_Lim	float	BW	A1_multipurpose_plan.
🗄 🔄 A1_mutipurpose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_AL_Lim#0.p_Level	uint	RW	A1_multipurpose_plan.
🖲 🛄 A1_mutipurpose_plant	A1_multipurpose_plant/T2_reaction/reactordR001/A1T2L001/Monitor_A1T2L001.PV_Hyst	float	RW/	A1_multipurpose_plan.
A1_multipurpose_plant	A1_multipurpose_plant/T2_reaction/reactordR001/A1T2L001/Monitor_A1T2L001.PV_Hyst#Op_Level	uint	BW	A1_multipurpose_plan.
A1_multipurpose_plant	A1_multipurpore_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_0pS cale#High A1_multipurpore_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_0pS cale#Low	float float	RW BW	A1_multipurpose_plan. A1_multipurpose_plan.
B A1_multipurpose_plant	A1_multipuppose_plant/12_reaction/reactor\$R001/A112L001/Monitor_A112L001.PV_Out#V alue	float	BW	A1_multipurpose_plan.
A1_mutipurpose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_Out#Value#short.	string	B	A1_multipurpose_plan.
A1_mutipurpose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_Unit	short	RW	A1_multipurpose_plan
B A1_multipurpose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_Unit#unit	string	R	A1_multipurpose_plan.
A1_multipurpose_plant	A1_multipurpose_plant/T2_reaction/reactordR001/A1T2L001/Monitor_A1T2L001.PV_WH_Lim	float	RW.	A1_multipurpose_plan.
B _ A1_multipurpose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_WH_Lim#Op_Le	uint	RW RW	A1_multipurpose_plan.
B A1_multipurpose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_WL_Lim A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_WL_Lim#Op_Lev.	ficat	RW BW	A1_multipurpose_plan. A1_multipurpose_plan.
8 A1_multipurpose_plant 8 A1_multipurpose_plant	A1_inditipuipose_plano12_leaction/reactor#R001/A112L001/Monitor_A112L001.SelFp1#Jump	string	B	A1_multipurpose_plan.
H- A1_multpurpose_plant H- A1_multpurpose_plant	A1_multipurpose_plant/T2_reaction/reactordR001/A1T2L001/Monitor_A1T2L001.SeFp1#0.S_Text	string	B	A1_multipurpose_plan.
H- A1_multipurpose_plant H A1_multipurpose_plant	A1_multipurpose_plant/T2_reaction/reactordR001/A1T2L001/Monitor_A1T2L001.Sim0 n	bool	RW	A1_multipurpose_plan.
Al_mutipurpose_plant	A1_multipurpose_plant/T2_reaction/teactordR001/A1T2L001/Monitor_A1T2L001.SimOn#Op_Level	uint	RW.	A1_multipurpose_plan.
Al_mutpurpose_plant Al_mutpurpose_plant	A1_multipurpose_plant/T2_reaction/reactordR001/A1T2L001/Monitor_A1T2L001.S imPV	float	RW	A1_multipurpose_plan.
Al_mutipurpose_plant Al_mutipurpose_plant	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.SimPV#0p_Level A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.ST_Worst	uint ubote	RW RW	A1_multipurpose_plan. A1_multipurpose_plan.
A1_mutpurpose_plant A1_mutpurpose_plant	A1_multipurpose_plant/12_reaction/reactor\$R001/A112L001/Monitor_A112L001.S1_Worst A1_multipurpose_plant/T2_reaction/reactor\$R001/A112L001/Monitor_A112L001.Status1	ubyte uint	BW	A1_multipurpose_plan. A1_multipurpose_plan.
B· Ki mutpupote part	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.Status2	uint	BW	A1_multipurpose_plan.
A1_mutipurpose_g	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001. StepNo	uint	RW	A1_multipurpose_plan.
- A1 millioumose r	A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.UserStatus	ubyte	RW	A1_multipurpose_plan.
	1			
orkbook 👻 🕈 🛪 🗙	KDA view 1			
5 5 3 9 9	-dimension			
	🔒 Monitoring DN 🛃 Generate values DN 🛄 Read	1	Write	
roject 'New project'				
> Server		de concelh		
🗁 COM server	ID Display name Type Access rights Time sta	mp (UTC)	Value	Quality Res
XML server	Real Provide American Science Provide American			
Views	10 To			
Views DA view 1	۲. III			

Unrestricted for Educational and R&D Facilities. © Siemens AG 2015. All Rights Reserved. P03-02_Vertical Integration with OPC_V8.1_S0915_EN.docx

 Next, click on 'Monitoring ON'. Now, in addition to other information, we can monitor the value, time stamp and quality. This shows you whether the 'OPCServer.WinCC' works faultlessly. (→ Monitoring ON)



 If this is the case, open the Microsoft Excel file included in the module with a double click. (→ PCS7_SCE_0302_OPC_Template_R1305_en.xls)



11. Then, save it in Microsoft Excel under a new name.

 $(\rightarrow \text{File} \rightarrow \text{Save As} \rightarrow \text{PCS7}_\text{SCE}_0302_\text{OPC.xls})$

X Save As	POLICE POLICE AND DESCRIPTION	on the Marsh had to come a	×
🕞 🗢 🗖 Desktop 🔸		✓ Search Desktop	٩
Organize 🔻 New folder			
🔣 Microsoft Excel	Libraries System Folder	plt-admin System Folder	
★ Favorites ■ Desktop ● Downloads	Computer System Folder	Network System Folder	
Secent Places Libraries			
Documents	v		
File name: PCS7_SCE_0302_0	PC_PV_Value_01_en.xls		•
Save as type: Excel 97-2003 Work	kbook (*.xls)		•
Authors: TUD; MDE	Tags: Add a tag	Title: Add a title	
Save Thum	bnail		
🔿 Hide Folders		Tools 👻 Save	Cancel

12. In Microsoft Excel, we now have to set the security settings correctly for the macros to be started.

 $(\rightarrow$ Developer \rightarrow Macro Security \rightarrow Macro Settings \rightarrow Disable all macros with notification \rightarrow OK)

File Home Insert Page Layout Form	ulas Data Review View	Developer 🔊 🗖 🖬 🔀
	OM Insert Design s Controls	e Expansion Packs Packs Packs
I Security M Macro Security	Enable Content	×
B2 Customize the macro security settings. 5	;	·
A PCS7OSC Press F1 for more help.		B C D E C Quality TimeStamp
A1_multipurpose_plant/T2_reaction/reactor\$R00	1/A1T2T001/Control_A1T2T001.PV	
6		
	T 10.1	? <mark>- x</mark>
9	Trust Center	
10 11 12	Trusted Publishers	Macro Settings
13 14	Trusted Locations	Disable all macros without notification
15	Trusted Documents	 Disable all macros with notification
17	Add-ins	Disable all macros except digitally signed macros
19	ActiveX Settings	Enable all macros (not recommended; potentially dangerous code can run)
21	Macro Settings	Developer Macro Settings
23	Protected View	Trust access to the <u>VBA</u> project object model
25	Message Bar	
27	External Content	
29	File Block Settings	
31 32	Privacy Options	
22 II → H Tabelle1 Ready		OK Cancel
4 5 6 7 8 9 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 32 32 32 32 32 32 32 32 32	Trusted Locations Trusted Documents Add-ins ActiveX Settings Macro Settings Protected View Message Bar External Content File Block Settings	Macro Settings Disable all macros without notification Disable all macros with notification Disable all macros except digitally signed macros Enable all macros (not recommended; potentially dangerous code can run) Developer Macro Settings Trust access to the YBA project object model

13. Then, in 'Options', activate the macros for this session.

 $(\rightarrow \text{Options} \rightarrow \text{Enable Content} \rightarrow \text{OK})$

File Home Insert Page Layout Formul	as Data Review View Devel	oper			۵ 🕜 🗖	er 23
Visual Macro &						
Security Warning Macros have been disabled.	Enable Content					×
B2 • (* <i>f</i> * 20.00145						~
A A PCSTOSCLIENT3 A1_multipurpose_plant/T2_reaction/reactor\$R001, 4 5 6 7	A1T2T001/Control_A1T2T001.PV#Value	B Quality 201 C0	C /	D TimeStamp	E	
8 9 10 11 12	Security Warning		-		8	x
13 14 15 16 ₩ Tabelle1 / ? / Ready 🗂	This file is on a network location may be able to the what's the risk?		rs who ha			:
	Do not <u>a</u> sk me again	for network files		Yes	<u>N</u> o	

14. . For the additional settings, open 'Visual Basic' in Microsoft Excel.


$(\rightarrow \text{Developer})$	$r \rightarrow V$ isual	Basic)							
File Home Insert Page	Layout Formulas	Data Review View	Develope	er				ے 😮 م	er 23
Visual Macros Basic Code	Add-Ins Add-Ins	Insert Mode Controls Properties Properties Properties Run Dialog Controls		Map Properties Expansion Packs Refresh Data XML		Document Panel Modify			
Visual Basic (Alt+F11)	<i>f</i> _x 20.00145								~
Open the Visual Basic editor.	A			В		С	D	E	-
3 4 5	ion/reactor\$R001/A1T	2T001/Control_A1T2T001.PV#	Value		Quality 0 C0 0		TimeStamp		
6 7 8 9 10									=
11 12 13									
14 15 16 17									
18 H I I I Tabelle1				[] ↓ [▼ ▶
Ready 🛅							100% —		- + ";;

- 15. There, under 'Tools' open the option 'References'. (\rightarrow Tools \rightarrow References)
- 16. For the variables to be accessed in OPCServer 'WinCC', the reference to the dll 'Siemens OPC DA Automation 2.0' has to be activated; if this reference is not available, it has to be entered here with 'Browse'. The path is then 'C:\Program Files\Common Files\Siemens\opc\sopcdaauto.dll'.

 $(\rightarrow$ Siemens OPC DA Automation 2.0 \rightarrow Browse \rightarrow C:\Program Files\Common Files\Siemens\opc\sopcdaauto.dll \rightarrow OK)

者 Microsoft Visual Basic	for Applications - PCS7_S	CE_0302_01	PC_PV_Value_01_en.xls			- • ×
<u>Eile Edit View I</u>	nsert F <u>o</u> rmat <u>D</u> ebug	Run Too	ls <u>A</u> dd-Ins <u>W</u> indow <u>H</u> el	р	Type a question	n for help 👻
- 🔜 📼 - 🔛 🕹 🗈	BA 901	II 🖬 🖏	References	Col 1		
Project - VBAProject		×	Additional Controls	M		
III III III		F	Macros	_en.xls - Tabelle1 (Code)		
	7 SCE 0302 OPC PV Va		Options	 (Declarations) 		▼ 3
Microsoft Excel			_			1
DieseArbeit			VBAProject Properties			
Tabelle 1 (Ta	abelle 1)		Digital Signature			
Tabelle1 Tabelle1 Tabelle1 Worksheet Alphabetic Categorized			Const ServerName = " Dim WithEvents MyOPC	Server As OPCServer		
(Name)	Tabelle 1		References - VBAProje	ect		
DisplayPageBreaks	False					
DisplayRightToLeft EnableAutoFilter	False		I Available References:			OK N
EnableCalculation	True					
EnableFormatConditionsCa						Cancel
EnableOutlining	False		Microsoft Excel 14.	0 Object Library		
EnablePivotTable	False					
EnableSelection	0 - xlNoRestrictions		✓ Microsoft Office 14			Browse
Name	Tabelle 1	_	Siemens OPC DAA			
ScrollArea		- 11		nin 1.0 Type Library	T	
StandardWidth Visible	8.43 -1 - xlSheetVisible	- 11	Acrobat Access 3.0) Type Library		
VISIDIE	-1 - XISHEEUVISIDIE		AcroIEHelper 1.0 T	wpo Library	Priority	Help
			AcroIEHelperShim			
			Active DS Type Lib		•	
			ActiveLinkClient 1.			
			ActiveMovie contro			
			Adobe 3D Utility 1.	<u>0 Type Library</u>	T	
			I I I I I I I I I I I I I I I I I I I		•	
			Siemens OPC DAAut	omation 2.0		
			Location: C	: \Program Files \Common File	es \Siemens \opc \sopc	daauto.dll
			Language: 9	Standard		

17. Now, the computer name has to be entered in field A1. We can copy it in WinCC under Computer properties. In field A2, the complete variable name has to be entered; it can be copied from the OPC Scout V10. (→ A1 → PCS7OSLIENT3 → A2 → A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV# Value)




File Home	Insert Page Lay	rout Formulas	Data Re	view View Dev	eloper					~	• •	æ X
Paste d B I	<u>u</u> • 🖂 • 🗸		= <mark>- </mark>				Formatting * as Table	Cell • Styles •	B™ Insert ▼ Pelete ▼ Format ▼	2 [×] F	int & Fin	nd & lect *
Clipboard 🕞	Font	Ga	Alignm				Styles		Cells		Editing	
A2	(°	🕼 A1_multipu	rpose_plant/T2	_reaction/reactor\$R	001/A1T2L	01/Monitor	_A1T2L001.PV#Value					~
4		А				В	С		D		E	
1 PCS7OSCLIENT							Quality	TimeSta	imp			
	plant/T2 reaction	/reactor\$R001/A	1T2L001/Monito	A1T2L001.PV#Valu		31	C0					
3						0						_
4 5												
6												
7												
8 9 10												
10												
11												
12												
13												_
14												
11 12 13 14 15 16 17												
17												
18												
	/ t											▶ []
Ready 🔚									100% (-		0	+

18. Next, save and close the Microsoft Excel file prior to reopening it with a double click. $(\rightarrow \text{Save} \rightarrow \square \rightarrow \text{PCS7}_\text{SCE}_0302_\text{OPC.xls})$

				/				
X 🖳 🔊 - (° -		SCE_0302_OPC_PV_Value_	01_en.xls [Compatibility	Mode] - Microsoft Exc	el			×
File Save (Ctrl+S)	Insert Page Layout Fo	ormulas Data Rev	riew View Devel	oper			ם 🕥 ۵	er 23
Arial	• 10 • A A	= = *	📑 Wrap Text	General	Conditional Format	Cell	Σ · Z · Z ·	ħ
Paste 🦪 🦉	I U • 🖽 • 🌺 • 🗛 •	医普通 律律	📑 Merge & Center 🔻	\$ * % *	Formatting * as Table			
Clipboard 🕞	Font G	Alignm	ent 🕞	Number	5 Styles	Cells	Editing	
A2	√ (f _x A1_m	ultipurpose_plant/T2	_reaction/reactor\$R00	01/A1T2L001/Monito	r_A1T2L001.PV#Value			~
4		Α		В	С	D	E	=
1 PCS70SCLIEN					Quality	TimeStamp		
	e plant/T2 reaction/reactor\$F	R001/A1T2L001/Monitor	A1T2L001.PV#Value	31	C0			
3				(
4								
5								_
6								
7								
8 9								
10								
11								
12								
13								
14								
15								
16 17								
17								
18								
I I I I I I I I I I I I I I I I I I I	1 / 💱 /							▶
Ready 🎦						🔲 💷 🛄 100% 😑)	-+ ,;


19. During opening, we take note of the security warning and here also, we enable the macros for the following session. (→ Options → Enable macros)



20. Now, in field B2, the variable can be monitored.

	officiality Data Revie	w View Devel	oper) ۵	
Arial • 10 • A A	≡ =	Wrap Text	Number	-	insert *	Σ·Α	r Ah
Paste B _ U		🕶 Merge & Center 👻	\$ ~ % , .0 .0	Conditional Format	Cell	Sort	
Clipboard 🖙 Font 🕫	a Alignmen	nt 🕠	Number		Cells		
B2 • (1489						~
1 PCS7OSCLIENT3	А		В	C	D	E	
	R001/A1T2L001/Monitor_/	A1T2L001.PV#Value	6100354			12:30	
3 4			0				
5							
6 7							
8							=
9 10							
11							
12 13							
14							
15							
17							
18 II I I Tabelle1					111		▶ [
Ready 🛅					100%	\ominus \Box	
(unknown) - Siemens AG - OPC Scout V10							• ×
	ols Window Help						
🚆 Server Explorer	Image: Second Second VID Image: Second VID Tabelies 1 Image: Second VID Tabelies 1 Image: Second VID View results Image: Second VID View re						
Server Explorer	n-1-1:x L m +						• • ×
DPCServer.WinCC							• • ×
	tems Properties					-	ts ID ^
OPCServer.WinCC G@LOCALMACHINE:: BInternal tags BIsto fal structure instances	tems Properties	plant/T2_reaction/reactor	R001/A1T2L001/Monitor		string	R	ts ID ^
DPCServer.WinCC DPCSERVER.WINCC DPCSERVER.WINC	Image: Rems Properties A1_multipurpose A1_multipurpose A1_multipurpose A1_multipurpose	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	\$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_	A1T2L001.#blocktype A1T2L001.#comment	string string string	R R R	ts ID ^ A1_ A1_ A1_ A1_
OPCServer.WinCC O	Items Properties A1_multipurpose_ A1_multipurpose_ A1_multipurpose_ A1_multipurpose_ A1_multipurpose_ A1_multipurpose_	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	\$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_	A1T2L001.#blocktype A1T2L001.#comment A1T2L001.#StatusPermaner A1T2L001.#TextPermanent	string string string nt uint string	R R R RW RW	ts ID ^ A1_ = A1_ = A1_ A1_ A1_ A1_ A1_ A1_ A1_ A1_ A1_ A1_
OPCServer.WinCC OPCServer.WinCC OPCServer.WinCC OPCServer.WinCC Utofal structure instances Utofal structure instances Officient inspace SIMATIC S7 Protocol Suite Officient Officient Officient Industrial Ethemet Officient Industrial Ethemet (II)	Items Properties A1_multipurpose_ A1_multipurpose_ A1_multipurpose_ A1_multipurpose_ A1_multipurpose_ A1_multipurpose_	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	\$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_	A172L001.#blocktype A172L001.#comment A172L001.#StatusPermane A172L001.#TextPermanent A172L001.BatchID	string string nt uint string uint	R R RW RW RW	ts ID A A1 E A1 A1 A1 A1 A1 A1 A1
OPCServer.WinCC O	Rems Properties A1_multipurpose A	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	\$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_ \$R001/A1T2L001/Monitor_	A1T2L001.#blocktype A1T2L001.#comment A1T2L001.#StatusPermanen A1T2L001.#TextPermanent A1T2L001.BatchID A1T2L001.BatchName A1T2L001.BatchName	string string nt uint string uint string float	R R RW RW RW RW RW	ts ID ^ A1 A1 A1 A1 A1 A1 A1 A1_
OPCServer: WinCC OPCS	Items Properties A1_multipurpose_ A1_multipurpose_ A1_multipurpose_ A1_multipurpose A1_multipurpose	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	SR001/A1T2L001/Monitor SR001/A1T2L001/Monitor SR001/A1T2L001/Monitor SR001/A1T2L001/Monitor SR001/A1T2L001/Monitor SR001/A1T2L001/Monitor SR001/A1T2L001/Monitor SR001/A1T2L001/Monitor SR001/A1T2L001/Monitor	A1T2L001.#blocktype A1T2L001.#comment A1T2L001.#StatusPermanent A1T2L001.#TextPermanent A1T2L001.BatchID A1T2L001.BatchIName A1T2L001.DeadBand#Op_L- A1T2L001.DeadBand#Op_L- A1T2L001.EventRaw#1	string string nt uint string uint string float evel uint uint	R R RW RW RW RW RW RW RW RW	ts ID
OPCServer.WinCC O	Items Properties A1_multipurpose A1_multipurpose	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor,	ATT2L001 #blocktype ATT2L001 #comment ATT2L001 #comment ATT2L001 #StatusPermanent ATT2L001 #StatusPermanent ATT2L001 BetchName ATT2L001 DeadBand ATT2L001 DeadBand ATT2L001 EventBaw#1 ATT2L001 EventState	string string string uint uint string float evel uint int	R R RW RW RW RW RW RW RW RW RW	ts ID AL. AI. AI. AI. AI. AI. AI. AI. AI. AI. AI
OPCServer: WinCC GelCoLMACHNE:: GELCOL	Items Properties A1_multipurpose_ A1_multipurpose_	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_	ATT2.001.#blocktype ATT2.001.#comment ATT2.001.#StatusPermanent ATT2.001.#StatusPermanent ATT2.001.BatchID ATT2.001.BatchID ATT2.001.BeadBand ATT2.001.EeadBand ATT2.001.EventRaw#1 ATT2.001.EventState ATT2.001.EventState ATT2.001.EventState ATT2.001.EventState ATT2.001.EventState	string string string nt uint string float float evel uint int uint bool	R R RW RW RW RW RW RW RW R RW R RW R R	ID A1_ A1_ A1_
OPCServer: WinCC GeCCALMACHINE:: GeLICALMACHINE:: GILICALMACHINE:: GELICALMACHINE:: GELICALMACHINE:: GELICALMACHINE:: GELICALMACHINE:: GELICALMACHINE::	Items Properties A1_multipurpose A1_multipurpose	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_ SR001/A1T2L001/Monitor_	ATT2.001.#blocktype ATT2.001.#comment ATT2.001.#StatusPermanent ATT2.001.#StatusPermanent ATT2.001.BatchID ATT2.001.BatchID ATT2.001.BeadBand ATT2.001.DeadBand#Op_L- ATT2.001.EventRaw#1 ATT2.001.EventState ATT2.001.EventState ATT2.001.EventState ATT2.001.EventState ATT2.001.EventState	string string string nt uint string float float evel uint int uint bool	R R RW RW RW RW RW RW RW R RW R RW R R	ID A1_ A1_ H A1_ A1_
OPCServer: WinCC GeCCALMACHINE:: GeLOCALMACHINE:: GELOCALMACHINE:: GELOCALMACHINE:: GELOCALMACHINE:: GELOCALMACHINE::	Items Properties A1_multipurpose_ A1_multipurpose_	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor,	ATT2.001 EMocKtype ATT2.001 Formment ATT2.001 #StatusPermaner ATT2.001 #StatusPermaner ATT2.001 #ATT2.001 BatchName ATT2.001 BatchName ATT2.001 DesdBand ATT2.001 DesdBand ATT2.001 EventState ATT2.001 EventState ATT2.001 EventState	string string string nt uint string tring float evel uint uint uint uint bool	R R RW RW RW RW RW RW RW R RW R RW R R	ID A1_ A1_ H A1_ A1_
	Items Properties A1_multipurpose_ A1_multipurpose_	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor,	ATT2.001 EMocKtype ATT2.001 Formment ATT2.001 #StatusPermaner ATT2.001 #StatusPermaner ATT2.001 #ATT2.001 BatchName ATT2.001 BatchName ATT2.001 DesdBand ATT2.001 DesdBand ATT2.001 EventState ATT2.001 EventState ATT2.001 EventState	string string string nt uint string tring float evel uint uint uint uint bool	R R RW RW RW RW RW RW RW R RW R RW R R	ID A1_ A1_ H A1_ A1_
OPCServer.WinCC CCLMACHINE:: CLut of all structure instances	Items Properties A1_multipurpose_ A1_multipurpose_	plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor	SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A172L001/Monitor SR001/A1721/01/Monitor	ATT2L001 Eblocktype ATT2L001 #comment ATT2L001 #CastuePermaner ATT2L001 #CastuePermaner ATT2L001 #CastPermaner ATT2L001 ExectRawf1 ATT2L001 BatchName ATT2L001 ExectRawf1 ATT2L001 ExectRa	string string string uint string uint string float evel uint uint uint uint bool d Mrite	R R R RW RW RW RW RW RW RW RW RW RW RW	IS ID А А1_ II А1_ II А1_ A1_ А1_ A1_ А1_ A1_ А1_ A1_ А1_ A1_ А1_ A1_ А1_ A1_ А1_ X1_ Х
	Items Properties A1_multipurpose_ A1_multipurpose_ B1_multipurpose_ A1_multipurpose_	plant/T2_reaction/reactor plant/T2_reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reactor plant/T2_reactor plant/T2_reactor pl	SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor,	ATT2.001 EMocKtype ATT2.001 EMoment ATT2.001 EXamplemane ATT2.001 EXamplemane ATT2.001 BatchName ATT2.001 BatchName ATT2.001 Exembard ATT2.001 Exembard ATT2	string string string unt string unt string float unt int wint bool vint d (" Write tamp (UTC)	R R RW RW RW RW RW RW RW RW RW RW SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/	IS ID ▲ AI_ H AI_ H AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ XI_ X Quality
	Items Properties A1_multipurpose_ A1_multipurpose_ B1_multipurpose_ A1_multipurpose_	plant/T2_reaction/reactor plant/T2_reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reactor plant/T2_reaction/reactor plant/T2_reactor plant/T2_reactor pl	SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor,	ATT2.001 EMocKtype ATT2.001 EMoment ATT2.001 EXamplemane ATT2.001 EXamplemane ATT2.001 BatchName ATT2.001 BatchName ATT2.001 Exembard ATT2.001 Exembard ATT2	string string string unt string unt string float unt int wint bool vint d (" Write tamp (UTC)	R R RW RW RW RW RW RW RW RW RW RW SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/	IS ID ▲ AI_ H AI_ H AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ XI_ X Quality
	Items Properties A1_multipurpose_ A1_multipurpose_ B1_multipurpose_ A1_multipurpose_	plant/T2_reaction/reactor plant/T2_reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reactor plant/T2_reaction/reactor plant/T2_reactor plant/T2_reactor pl	SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor,	ATT2.001 EMocKtype ATT2.001 EMoment ATT2.001 EXamplemane ATT2.001 EXamplemane ATT2.001 BatchName ATT2.001 BatchName ATT2.001 Exembard ATT2.001 Exembard ATT2	string string string unt string unt string float unt int wint bool vint d (" Write tamp (UTC)	R R RW RW RW RW RW RW RW RW RW RW SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/	IS ID ▲ AI_ H AI_ H AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ XI_ X Quality
	Items Properties A1_multipurpose_ A1_multipurpose_ B1_multipurpose_ A1_multipurpose_	plant/T2_reaction/reactor plant/T2_reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reaction/reactor plant/T2_reactor plant/T2_reaction/reactor plant/T2_reactor plant/T2_reactor pl	SR001/A1T2L001/Monitor, SR001/A1T2L001/Monitor,	ATT2.001 EMocKtype ATT2.001 EMoment ATT2.001 EXamplemane ATT2.001 EXamplemane ATT2.001 BatchName ATT2.001 BatchName ATT2.001 Exembard ATT2.001 Exembard ATT2	string string string unt string unt string float unt int wint bool vint d (" Write tamp (UTC)	R R RW RW RW RW RW RW RW RW RW RW SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/ SN/	IS ID ▲ AI_ H AI_ H AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ AI_ XI_ X Quality

21. In field B3, a new value can be written for the variable. We cannot use the process value as above because it would overwrite itself immediately. It is best to use a fixed parameter, for example, A1_multipurpose_plant/T2_reaction/reactor\$R001/A1T2L001/Monitor_A1T2L001.PV_AH_Lim to test this functionality. With the OPC Scout, change the value to 1005, and then with the Excel file back to 1000.



File	Home Insert	Page Layo	out Formulas	Data Review View	Develop	er				۵ 🕜 🗆	æ X3
Visual Basic	🔔 Macro Sec	ve References	Add-Ins COM Add-Ins	Insert Design Mode 1 Run Dialog		Expansion Packs	Export @	Document Panel			
	Code		Add-Ins	Controls		XML		Modify			
	B4 👻	🖱 fs	r								~
			A			В		С	D	E	
	S7OSCLIENT3						Quality		TimeStamp		
	_multipurpose_plant	T2_reaction/	reactor\$R001/A1T	2L001/Monitor_A1T2L001.PV_	AH_Lim		0 C0		05/13/2015 13:01		
3						100	0				
4							-				
5											
6											
7											
8											
9											
10 11											
1											
12											
12 13 14											
15											L
16											
15 16 17											
18											
	🕅 Tabelle1 🤇 💱	/					1				▶ [
Ready	2								III II 100% 🗩		+

EXERCISES

In the exercises, we apply what we learned in the Theory section and in the Step by Step Instructions.

The existing multi-project PCS7_SCE_0301_Ueb_R1504_en.zip and the table PCS7_SCE_0302_OPC_Template_R1305_en.xls will be used for this.

The objective of this exercise is: identifying and reading a measured value by means of an OPC item.

TASKS

- 1. Using PCS 7 and the OPC Scout, identify the corresponding variable name of temperature measurement in Reactor R001.
- 2. Modify the variable name in the table from the step by step instructions with the new name and read out the value.